

PAINTED CENTER CAPS INSTRUCTIONS

TOOLS NEEDED



- JACK
- JACK STAND
- 22MM SOCKET AND BREAKER BAR OR FACTORY TIRE IRON

WHATS INCLUDED

- 4 CENTER CAPS

1. JACK CAR UP
2. REMOVE WHEEL
3. LAY WHEEL FACE DOWN
4. USE FINGER TO PUSH OUT CENTER CAP
5. FLIP WHEEL OVER
6. PRESS IN NEW CENTER CAP
7. RE INSTALL WHEEL AND TIRE
8. LOWER CAR AND ENJOY