



First open chest strap and waist belt buckles. Place waist belt around your hips.

Close waist belt buckle in front of you. Adjust size of waist belt to fit tight. Roll

excessive webbing up and secure with elastic band on the end.

Sit your baby around your waist with her legs on

either side of you. Bring body of carrier up over baby's back. With one hand supporting your baby,

reach for shoulder strap with your free hand and

place it on your shoulder. Switch hands and place the second shoulder strap on your shoulder. Make sure your baby is centered in the carrier.







Turn waist belt around and open shoulder strap buckle on each side. Make sure body of carrier is centered in front of you.









Reach back for end of shoulder strap and bring it

across your back. Holding baby with your forearm, use both hands to close shoulder strap

buckle on side of the carrier.

Adjust size of shoulder strap by pulling toward yourself. Make sure the fit is tight and safe.







On each shoulder strap, roll excessive webbing up and secure with elastic band on the end.







For babies with head and neck control, you may bring the head rest down. Open head rest buckle on each shoulder strap, fold head rest down and attach it to snaps on each side of the carrier.



FRONT CARRY FACING IN

Note: See becobabycarrier.com for 'BACKPACK STYLE' FRONT CARRY POSITION

centered above waist belt.



First open chest strap, shoulder strap and waist belt buckles.

Open waist belt snaps on each side and attach them to snaps





Open head rest buckle on each shoulder strap, fold head rest down and attach it to snaps on each side of the carrier.



2.3







Place waist belt around your hips and close waist belt buckle. Adjust size of waist belt to fit tight. Roll excessive webbing Hold your baby on front of your body. With your free hand, bring body of carrier up over your baby with her legs on either side of carrier. Make sure your baby is centered in the carrier. up and secure with elastic band on the end. Make sure body of carrier is centered in front you. With one hand supporting your baby, reach for shoulder strap with your free hand and place it on your shoulder.











On each shoulder strap, roll excessive webbing up and secure with elastic band on the end.





FRONT CARRY FACING OUT

## TRI-LOCK BUCKLES The GEMINI Baby Carrier is equipped with very secure tri-lock buckles. Once properly fastened, these buckles will not open accidentally.


TO OPEN: Squeeze the sides of the buckle with one hand and push the button on buckle's top with your other hand. Pull the buckles apart.



Line up the parts of the buckle and slide them together until you hear a solid "click". Pull gently on the buckle parts to ensure they are properly aligned and engaged. Always listen for that click!







supportive waist belt 27' up to 59'

**GEMINI INSTRUCTIONS** 











First open chest strap and waist belt buckles. Open head rest buckle on each shoulder strap, fold head rest down and attach it to snaps on each side of the

Place waist belt around your hips. Close waist belt buckle in front of you. Adjust size of waist belt to fit tight.



Roll excessive webbing up and secure with elastic band on the end.



Turn waist belt around. Make sure body of carrier is centered in front of you.





Before you master this step, do so over a bed or other soft surface. Initially, assistance of another person is helpful too. Sit your baby around your waist with her legs on either side of you. Holding baby and the carrier with one arm bend forward and slide your baby in the carrier around your hips toward and onto your lower back. Use your free arm to slide waist belt around your hips more easily.



Once your baby sits centered on your lower back, place shoulder straps on your shoulders one at a

Adjust size of shoulder straps by pulling upward.

Make sure the fit is tight and safe.



Close chest strap in front of you and adjust the fit by pulling sideways onto its free end. Chest strap should be at collar bone level.



On each shoulder strap, roll excessive webbing up and secure with elastic band on the end.

Note: Practice in front of a mirror first. Keep eye contact with your baby, bounce slightly up and down and talk in a soft voice.



BACK CARRY





First open chest strap and waist belt buckles. Open head rest buckle on each

shoulder strap, fold head rest down and attach it to snaps on each side of the



Place waist belt around your hips. Close waist belt buckle in front of you. Adjust size of waist belt to fit tight. Roll excessive webbing up and secure with elastic band on the end.



Open both shoulder strap buckles.

Bring right shoulder strap buckle to left side of

carrier's body and close the buckle. Leave left









Put your left arm through . Bring shoulder strap over your head onto your right shoulder. Adjust length of shoulder strap to create a pouch of your baby size. Slide carrier onto your left hip.



shoulder strap loose.



Place your baby into carrier. Make sure baby is centered within carrier on your hip.

Reach behind your back for other shoulder strap, wrap it around your waist and







Adjust size of shoulder strap by pulling toward yourself. Make sure the fit is tight and safe. Roll excessive webbing up and secure with elastic band on the end.



## TRI-LOCK BUCKLES

The GEMINI Baby Carrier is equipped with very secure tri-lock buckles. Once properly fastened, these buckles will not open accidentally.

attach buckle on side of carrier.


TO OPEN: Squeeze the sides of the buckle with one hand and push the button on buckle's top with your other hand. Pull



# Line up the parts of the buckle and slide them together until you hear a solid "click". Pull gently on the buckle parts







# HIP CARRY



**GEMINI INSTRUCTIONS**