



WARNING!!!

Usage Disclaimer

Please READ before use.

Any damage, misuse or modification of this product may cause serious injury.

ONLY charge with the micro USB port on the bottom of the battery. Charging the battery any other way may result in fire and/or injury.

NEVER leave charging batteries unattended.

NEVER overcharge battery or leave on charger for extended periods of time.



Battery Controls

1. Charge battery fully before first time use.
2. Turn battery On / Off
 - Click battery button 5 times.
3. Enter Pre-Heat Mode
 - Click button 2 times to enter Pre-Heat mode. The battery light will blink slowly for a 5 second heating cycle. (Click button once to exit preheat mode.)
4. Variable Voltage
 - Click button 3 times to cycle thorough voltage. (Blue-2.7V, Green-3.4V, Red-4.2V)