

SPACE-STATION DISH RACK


KTH-775

ASSEMBLY INSTRUCTIONS


IMPORTANT: RETAIN FOR FUTURE REFERENCE, READ CAREFULLY.

For assistance with use, parts and customer service call (800) 431.2133 Monday through Friday, 9AM to 5PM EST, email info@polder.com or visit our website at www.polder.com. Customers in the UK can call +44 (0) 1243 780501 or visit www.polderproducts.co.uk

SPOUT ASSEMBLY:




Spout press-fits onto underside of Drain Tray




Press spout into drain mount located on the underside of the Drain Tray until you hear it snap-fit into place

SPOUT PLACEMENT:



Place Dish Rack horizontally and rotate spout away from washing area to drain water runoff directly into sink

OR



For a more narrow space place Dish Rack vertically and rotate spout to drain water runoff directly into sink