



Configuration Guide

TaHoma®



TaHoma works with Google Home & Google Assistant

1. GETTING STARTED

Download from the online stores the mobile app Google Home & Google Assistant



Google Home 12+

Your home in your hands

Google LLC

#4 in Lifestyle

★★★★★ 4.5 • 639.1K Ratings

Free



Google Assistant 17+


Your own personal Google

Google LLC



#101 in Utilities

★★★★★ 4.7 • 62K Ratings

Free




Make sure you have already some **devices added**, and **scenes created** in your **Tahoma Living Application**.





2. GOOGLE HOME SETTING

Launch the Google Home mobile app on your mobile phone





1. Open your Google Home application
2. Tap on "Settings"
3. Scroll down and select **Works with Google...**





4. Tap on “🔍” then type “somfy” in the search bar.

5. Select **Somfy Asia & Oceania**




6. Enter your TaHoma login (email address) and password to connect Google Home to Somfy Asia & Oceania smart services. (This operation is required only once).





Congratulation!

Now your Google account is
linked with Somfy Tahoma!




Lighting and window covering devices paired with TaHoma will be automatically discovered and appear on the interface.



3. ENABLE THE VOICE CONTROL

Now blinds, curtains and lights can be controlled even by with voice control with Google Assistant.



Devices able to be discovered by Google assistant.



Roller Shutters



Swinging Shutters



Exterior Venetian Blinds



Exterior Screens



Screens



Venetian Blinds



Curtains



Lights



On Off



Lights





blaster


Scenes will also be discovered by Google assistant. IRblaster command will be able to launch inside scenes.

3. SCENARIO & ROUTINE

To launch the Tahoma scenes by using your voice is necessary link them to routines





1. Tap on **Routines**.
2. Press on the **+** on the right down corner




Two type of routine can be created. Personal or common to all the user of the household.

Pressing “**Household**” or “**Personal**” is possible start the linking procedure

Routines require starting conditions and action to be executed





1. Tap on “**add starter**” for adding starting conditions
2. Write in the field the sentence triggering the scenario.



- ✓ Activate all the lights
- ✓ Activate the air conditioning
- ✓ Close all the lights


Tap on “**add starter**” for adding the devices and or the scenario to trigger with the voice command.

The right devices and scenarios have to be selected



1. Taping on **“Adjust Home Devices”** the list of devices present in the household will be listed.

2. Scrolling the list until the bottom will reveal the new option.



Is possible select either the devices present on the household installation and or include the Tahoma Scenario.


Routines require starting conditions and action to be executed




The Tahoma scenarios are listed in the picture on the left. To include them in the Google home routines, just check mark them.




When the routine is complete, it will look like the picture on the right. With a starting condition and an action to trigger.



The routines will be available for the activation in the main screen of Google Home.



Now all is done. You can launch your scene using the voice control, by saying the name of the scenario, the start condition **Activate #scene name #**.



- ✓ Projector turned on by IR blaster
- ✓ Projection screen lowered
- ✓ Lights turned on