HOWARD MILLER®

IMPORTANT NOTES

Keep all hardware parts out of reach of children. To avoid body injury or damage please ask someone for assistance when assembling. Check all screws & bolts periodically and tighten them when

needed. CARE & MAINTENANCE

Use a soft cloth to wipe clean all wood parts. Never use harsh chemicals or abrasives cleaners as they could damage the finish.

ASSEMBLY INSTRUCTION:

ITHACA PUB TABLE ASSEMBLY INSTRUCTION MODEL 699-010

PARTS LIST: (INCLUDED)

	Flat Washer	4 pieces
P	Lock Washer	4 pieces
	Bolt	4 pieces
	Wrench	1 piece
	Push Rod	2 pieces

- 1. Install Table Top and Base together using the hardware shown. Remove the Game Board from the Table Top prior to assembly and take care that Drawers do not slide out.
- 2. Install the Push Rods as shown.
- 3. Insall the Game Board into the Table Top. Adjust the Leveles as necessary.

