


Remote Functions & Instructions



1) Power On

Remote: Press the “Button A” (on the remote) for 1 second.

Board: Press the “Power” button on the board for 0.2 second.

2) Power Off

Remote: Press the “Button A” on the remote for 2 seconds.

Board: Press the “Power” button on the board for 1 second.

3) Throttle/Brake Control

Accelerate: Move the throttle forward to speed up.

Brake: Move the throttle backward to brake.

4) Power Indicators

Remote Power Indicator:

Red: 25%

Green: 25% ~ 100%

Board Power Indicator:

●●●● : 100%

○●●● : 75%

○○●● : 50%

○○○● : 25%

○○○○ : <12.5%

“●” means “solid”, “○” means “flash” and “○” means “die out”.

5) Switch of Skateboard Direction

Backward mode: Move the Switch C backward.

Forward mode: Move the Switch C forward.

6) Switch of Gears

Low-speed: Press the Button B, the board power LEDs will flash one by one slowly

High-speed: Press the Button B, the board power LEDs will flash one by one rapidly

Note: this operation effects only when the “throttle scroll wheel” is at the neutral position.

7) Charging

The remote power LED comes on Red and turns to Green when it's fully charged.