

Assembling Instruction for ES-6025

STEP 1

Release leg latches by pressing OFF. Then extend legs and lock them in place by pressing ON.



STEP 2

Turn lever to loosen canvas arm bracket.




STEP 3

Slide canvas support onto canvas arm until it reaches the bottom. The canvas arm can be locked into place by pressing the side of the latch marked ON.



STEP 4

Insert canvas arm up through canvas arm bracket and tighten lever to secure. NOTE: It may be necessary to temporarily remove thumbscrew from the back of the canvas arm to complete this step. Reinsert this thumbscrew after this step is complete.



STEP 5

Insert top canvas holder into canvas arm. The top canvas holder can be adjusted to fit your canvas. Secure the top canvas holder by tightening the thumb-screw on the back of the canvas arm.



STEP 6

There are two sets of attachment points for the large canvas tray. The size of your canvas and your preferred painting position will determine whether you will use the upper or lower attachment points. The attachment points can be raised or lowered using the same type of ON/OFF latch that extends the easel legs.



STEP 7

Attach the large canvas tray by placing the hole in the tray over the desired attachment points and pressing down. Please note that the large canvas tray has several accessories including folding palette holders, a fold out brush holder, and a hook and chain for hanging painting accessories.

