

# playzone-fit

PLZ.607 - Double Maze Board  
AGES 3+  
WEIGHT LIMIT: 150 lb (68 kg)

**Kit Contents:**

- (1) Balance Board
- (1) Reversible double board insert
- (3) Rubber balls

*Warranty: 1 year on all parts and workmanship*



**WARNING! ADULT SUPERVISION REQUIRED!**

Always exercise extreme caution when using the Maze Board.



**WARNING! ADULT ASSEMBLY REQUIRED!**

This product should be unpacked and assembled by an adult.



**WARNING! CHOKING HAZARD!**

Toy contains small parts. Not for children under 3 years of age.

# playzone-fit

Thank you for your purchase of the playzone™-fit Double Maze Board. For best and safe results, please read all instructions carefully when using your board. Read and obey all rules and warnings. We are sure this product will provide you with years of fun and exciting mental & physical development.

## **BE SAFE! ALWAYS FOLLOW THESE RULES**

- THIS PRODUCT IS INTENDED FOR USE BY CHILDREN FROM AGES 3+ YEARS OF AGE.
- Maximum weight 150 lbs (68 kg).
- To be setup and assembled by an adult and adult supervision is required at all times.
- Do not allow fingers or toes to be placed under the board!
- To prevent stumbling and falling into objects, clear all furniture and other objects at least 6ft away from the board position.
- For indoor or outdoor use, and domestic use only. If used outdoors, use under a covered porch or other covering structure. Do not use in bad weather conditions, bring the product indoors.
- Instruct children not to use the maze or board in a manner other than intended
- Use caution when stepping off of the maze board. Use Extreme Care at ALL TIMES
- Make sure the area is clear of obstacles, people and pets.
- Soft ground or carpeting is recommended to have under the board, for safer play and board ease of use.
- If worn or damaged parts are found, contact b4 ADVENTURE for replacement parts – DO NOT substitute with other, non-b4ADVENTURE parts or failure resulting in injury may result.

## **Assembly instructions (to be performed by an adult)**

- Remove all parts from box. Carefully inspect for any damage that may have occurred in shipping. Replace any worn or damaged pieces only with B4Adventure parts!
- Select a maze option to start them on. To change maze, simply pull out the maze at the start point (Figure 1) flip and re-insert into the frame.
- For the FIRST TIME (NOVICE) USER of the board, have them step on the board while holding another person's hands for extra balance, then have the user try releasing one hand first and then the other, until they get used to balancing on the board. Once they have gotten some experience, they should be able to step on the board without assistance.
- Using the game ball-Place the ball in the Start Ball position (Figure 1) Then navigate the ball through the maze. Try going both forward and then backward. Have somebody time how long it takes for added fun.
- TIP: when doing the maze, it helps to have your hands out from your sides (Figure 2)
- Maze can also be performed while holding the board and using your arms. (Figure 3)



Figure 1



Figure 2



Figure 3



### **Maintenance Checklist**

At the beginning of each play season (note: if used all year, perform these every month or more often if heavy use is experienced)

- Inspect for any damage (cracking/splitting) and DO NOT USE if any damage is found.
- Clean the board frame, maze (both sides), balls and Challenge insert with a mild soap and water solution. Do not use petroleum based cleaners or abrasives as these may damage the product.
- If used on a carpeted area, you may want to regularly move the location of the board, to prevent a wearing down of carpet fibers over time.

### **Disclaimer**

- The purchaser of this product assumes all liability for the assembly, installation, maintenance and use of this product.
- All the information provided by b4Adventure either printed, electronic or other, is not to be considered professional instruction or advice. Users of this equipment are encouraged to seek professional instruction regarding specific questions about usage, location, etc.

Please save these instructions for future reference.

Owners shall be responsible for maintaining the legibility of the warning labels.

### **Disposal instructions**

- Recycle your product according to Local, State, or Federal Laws.

PRODUCT CONFORMS TO ASTM F963, CONSUMER SAFETY PERFORMANCE SPECIFICATION FOR CHILDREN'S PRODUCTS.