


www.steelcut.design

INSTALL GUIDE

ANGLE BRACKET

The angle bracket can be used for Left or Right installations by rotating it 180°.





Top view



STEP1


Use included mounting hardware to mount angle bracket to the wall.





STEP 3

Attach keypad and faceplate to door station following the manufacturer's instructions.



NOTES