



www.bullshooter.com | www.arachnid360.com | 800.435.8319 | 815.654.0212 | Fax 815.654.0447

Spider 1000 Camera Kit

Kit# 44456

This kit allows you to install the optional player camera in your 1000 Series Spider 360 dartboard. Follow the below instructions:

Needed Tools

- A Phillips Head Screwdriver

1. Unplug the Spider 1000 from the wall outlet.
2. Open the target door.
3. Remove the plug from the camera opening.



Note: If you do not have the plug step 3 mentions, or has a predrilled hole there, you will likely need to drill out the hole yourself. For instructions on how to do that, visit:

<https://spider360.com/pages/support-s1000>

Download **Spider 1000 Camera Kit Rev A**. Follow those instructions instead.




4. Slide the camera USB cable through the opening.
 - ♦ The cable should drop down next to the ground plane.
 - ♦ The cable may get hung up and would require some coaxing from you.

5. Holding the camera bracket in place, use the supplied screws to secure the camera bracket in place.

Warning: Do not over tighten. Only snug the screws in place.





6. Plug the camera USB cable into the only available USB port on the control board.
7. Close and latch the darthead door.
8. Plug the machine back in.

