

User Manual

MODEL: USL445
Solar Jar Light | Crackle Glass Lantern |
40LED | SPARKLE



HOSELINK[®]

HOSELINK[®]

With its unique design, this Crackle Glass Jar Solar Light can illuminate any balcony, table or entertaining area. It can also be hung as a beautiful pendant light from a sunny pergola or tree branch.

Kit contains:

- Glass Crackle Jar Solar Light

PRODUCT INSTALLATION

Option 1

Placing the light: Simply position the light in a suitable location, making sure it has access to at least 8 hours of direct sunlight per day to fully charge.

Option 2

Hanging handle: All the hard work is done for you! Simply hang the light in your desired sunny location and away you go.

ACTIVATE LIGHT

To activate the light, lift off the aluminium lid that contains the solar panel from the jar, then press the button on the base to turn on. Press again to turn off.

Be careful not to pull too many of the lights out of the jar when doing this.

Test the light by covering the solar panel and checking if it illuminates. The built-in intelligent sensor will automatically light up at night and turn off at dawn.

Specifications

Solar panel	2V / 0.24W
LED lumens	5-6 lumens
Working time	7 hours
Lithium battery	600mAh / 1.2V
Light temperature (Kelvins)	3000-3200k
Charge time	8 hours

NOTE: DO NOT USE THIS LIGHT UNDERWATER OR IN LOW-LYING PUDDLES.



MODEL: USL445
Solar Jar Light | Crackle Glass Lantern |
40LED | SPARKLE

For more information visit

[hoselink.com](https://www.hoselink.com)

or call

(833) 216 4673

Cultivating **Connections**

 [youtube.com/hoselink](https://www.youtube.com/hoselink)