


INSTALLATION INSTRUCTIONS

DOUBLE CYLINDER LOCKSET



1. Position knob/plate or knob/rose assemblies and rings on door as shown so that spindles engage lock properly.

2. Screw in both cylinders firmly so that key slot is toward knob and aligned vertically.

3. Tighten both cylinder set screws and check lock operation with key.

4. Fasten screw(s) through inside plate(s) or rose into post(s) on out side plate or rose.