

TROUBLESHOOTING

NO.	Error code	Description	Cause / Solution
1	100	Excessive differential pressure	
2	110	Charging overvoltage protection	
3	140	Discharge undervoltage protection	
4	150	Discharge over-temperature protection	
5	160	Discharge under-temperature protection	
6	170	Temperature error	
7	200	Communication abnormalities	
8	201	Charging communication abnormal	
9	410	Undervoltage protection at start-up	
10	411	Under-voltage protection before start-up	
11	420	Activation of over-temperature protection	
12	430	External battery voltage is greater than the device voltage	
13	440	Ignition clip reverse connection	
14	450	Auto-start failure	
15	470	Pre-start differential pressure abnormality protection	
16	480	Wait 30 seconds for the next	