YOUR PENDANT

We recommend that a qualified electrician fits these lights.

Feed the lighting cable through the wooden surround until the bulb holder is in the correct position.

Fit the mounting bracket for the ceiling rose to the desired location.



Feed the lighting cable through the ceiling rose and ensure the cable gland is tightened. Fit the ceiling rose to the mounting bracket and connect to the mains.

The bulb can now be fitted. Please do not overtighten when fitting or replacing the bulb.

