


YOUR PENDANT

We recommend that a qualified electrician fits these lights.

Fit the mounting bracket for the ceiling rose to the desired location.

If the petals have loosened in transit they can be tightened using the allen key provided.



Feed the lighting cable through the ceiling rose and ensure the cable gland is tightened. Fit the ceiling rose to the mounting bracket and connect to the mains.

The bulb can now be fitted. Please do not overtighten when fitting or replacing the bulb.

