

# PROGRAMMING MACROS

MACRO	Left NUM Shift + Left FN Shift + ...
Swap Keys	F1, for 2 seconds
Copy Key	F2, for 2 seconds
Move Key	F3, for 2 seconds
Erase Key	F4, for 2 seconds
Combination	F5, for 2 seconds
Restore Key	ESC, for 2 seconds
Master Reset	DEL, for 5 seconds
Toggle Programming Text Guidance	F6, for 2 seconds
Toggle Lock Beeper	F7, for 2 seconds

Refer to the Freedom's Programming Guide for detailed guidance, or visit [www.zergotech.com](http://www.zergotech.com) for more information.

# DEFAULT COMBINATIONS

FN Layer Shortcut	Equivalent Windows Keys	Equivalent Mac OS Keys
Reverse Tab	Shift + Tab	Shift + Tab
Select All	CTRL + A	CMD + A
Save	CTRL + S	CMD + S
Find	CTRL + F	CMD + F
Undo	CTRL + Z	CMD + Z
Cut	CTRL + X	CMD + X
Copy	CTRL + C	CMD + C
Paste	CTRL + V	CMD + V
Bold	CTRL + B	CMD + B
Redo	CTRL + Y	-
Close	CTRL + W	CMD + W