


Bell Tube Bird Feeder Filling Instructions

Your Package Includes


1 - Bell Tube Bird Feeder

Filling the Bell Tube Bird Feeder

- 1. To fill the feeder, simply loosen the handle by turning counter clockwise.
- 2. Once loose, lift the roof off as shown to add bird feed.



3. Replace top and turn clockwise to tighten.



TELL US WHAT YOU THINK

Your opinion matters! Please review us on the site you purchased your Good Directions product. Your online review and feedback will help us be the best we can be!

Have a question? Let us help. help@gooddirections.com







