

## Bird Feeder Filling Instructions

## **Your Package Includes**

1 - Bird Feeder

- 1. To fill the feeder, simply loosen the handle 3. Turn plate back over opening and turn by turning counter clockwise.
- 2. Once loose, turn the plate as shown to add bird feed.





2. Once loose, turn the plate as shown to add bird feed.



- 1. To fill the feeder, simply loosen the handle 3. Turn plate back over opening and turn by turning counter clockwise.
- 2. Once loose, turn the plate as shown to add bird feed.



handle clockwise to tighten.



handle clockwise to tighten.



## TELL US WHAT YOU THINK

Your opinion matters! Please review us on the site you purchased your Good Directions product. Your online review and feedback will help us be the best we can be!

Have a question? Let us help. help@gooddirections.com







