

WARNING:

- After installation, please keep the machine vertical. Tilt or lie flatly may cause oil overflow. The machine efficiency may be affected if the circuit board is contaminated.
- Shall not modify, disassemble or repair the machine arbitrarily. Any failure happens, please contact relevant technician in time.
- Do NOT use quick charger for device.

Q&A

Q:Do not diffuse

- The atomizing core may be blocked, please clean the impurities inside with alcohol or replace a new one.
- Air pump may be damaged, please replace a new one.
- The tube may be loose, please check and tighten it.

Q:Weak diffuse

- The atomizing core may be blocked, please clean the impurities inside with alcohol or replace a new one.
- The gasket may be damaged or loose, please tighten it or replace a new one.
- The tube may be loose, please check and tighten it.

Q:Oil leakage

- The bottle may be loose, please check and tighten it.
- The gasket in the atomized head is damaged or loose, please tighten it or replace a new one.

Q:Oil spill

- The atomized head may be damaged, please replace a new one.
- The machine is tilted or lie flat, please keep it upright.

Q:Abnormal noise

- The air pump may be loose, please check and tighten it.
- The air pump may be damaged, please replace a new one.

PRODUCT MANUAL

SCENT MARKETING

A601

CAR & ROOM AROMA DIFFUSER

WARNING:

- After installation, please keep the machine vertical. Tilt or lie flatly may cause oil overflow. The machine efficiency may be affected if the circuit board is contaminated.
- Shall not modify, disassemble or repair the machine arbitrarily. Any failure happens, please contact relevant technician in time.
- Do NOT use quick charger for device.

Q&A

Q:Do not diffuse

- The atomizing core may be blocked, please clean the impurities inside with alcohol or replace a new one.
- Air pump may be damaged, please replace a new one.
- The tube may be loose, please check and tighten it.

Q:Weak diffuse

- The atomizing core may be blocked, please clean the impurities inside with alcohol or replace a new one.
- The gasket may be damaged or loose, please tighten it or replace a new one.
- The tube may be loose, please check and tighten it.

Q:Oil leakage

- The bottle may be loose, please check and tighten it.
- The gasket in the atomized head is damaged or loose, please tighten it or replace a new one.

Q:Oil spill

- The atomized head may be damaged, please replace a new one.
- The machine is tilted or lie flat, please keep it upright.

Q:Abnormal noise

- The air pump may be loose, please check and tighten it.
- The air pump may be damaged, please replace a new one.

PRODUCT MANUAL

SCENT MARKETING

A601

CAR & ROOM AROMA DIFFUSER

WARNING:

- After installation, please keep the machine vertical. Tilt or lie flatly may cause oil overflow. The machine efficiency may be affected if the circuit board is contaminated.
- Shall not modify, disassemble or repair the machine arbitrarily. Any failure happens, please contact relevant technician in time.
- Do NOT use quick charger for device.

Q&A

Q:Do not diffuse

- The atomizing core may be blocked, please clean the impurities inside with alcohol or replace a new one.
- Air pump may be damaged, please replace a new one.
- The tube may be loose, please check and tighten it.

Q:Weak diffuse

- The atomizing core may be blocked, please clean the impurities inside with alcohol or replace a new one.
- The gasket may be damaged or loose, please tighten it or replace a new one.
- The tube may be loose, please check and tighten it.

Q:Oil leakage

- The bottle may be loose, please check and tighten it.
- The gasket in the atomized head is damaged or loose, please tighten it or replace a new one.

Q:Oil spill

- The atomized head may be damaged, please replace a new one.
- The machine is tilted or lie flat, please keep it upright.

Q:Abnormal noise

- The air pump may be loose, please check and tighten it.
- The air pump may be damaged, please replace a new one.

PRODUCT MANUAL

SCENT MARKETING

A601

CAR & ROOM AROMA DIFFUSER

WARNING:

- After installation, please keep the machine vertical. Tilt or lie flatly may cause oil overflow. The machine efficiency may be affected if the circuit board is contaminated.
- Shall not modify, disassemble or repair the machine arbitrarily. Any failure happens, please contact relevant technician in time.
- Do NOT use quick charger for device.

Q&A

Q:Do not diffuse

- The atomizing core may be blocked, please clean the impurities inside with alcohol or replace a new one.
- Air pump may be damaged, please replace a new one.
- The tube may be loose, please check and tighten it.

Q:Weak diffuse

- The atomizing core may be blocked, please clean the impurities inside with alcohol or replace a new one.
- The gasket may be damaged or loose, please tighten it or replace a new one.
- The tube may be loose, please check and tighten it.

Q:Oil leakage

- The bottle may be loose, please check and tighten it.
- The gasket in the atomized head is damaged or loose, please tighten it or replace a new one.

Q:Oil spill

- The atomized head may be damaged, please replace a new one.
- The machine is tilted or lie flat, please keep it upright.

Q:Abnormal noise

- The air pump may be loose, please check and tighten it.
- The air pump may be damaged, please replace a new one.

PRODUCT MANUAL

SCENT MARKETING


A601

CAR & ROOM AROMA DIFFUSER


Car & Room Aroma Diffuser



Product: A601
Dimension: 70*133mm
Input Voltage: 5V
Power: 1.5W
Bottle Capacity: 10 ml
G.W.: 220g
Consumption: 0.03-0.07 ml/h
Coverage: 10m²




Directions:



Grade	Working (s)	Stop(s)
G1	6	360
G2	6	180
G3	10	280
G4	10	140

Operation:



When change oil bottle, the vent hole of bottle should be right towards the gap of the body.


Car & Room Aroma Diffuser



Product: A601
Dimension: 70*133mm
Input Voltage: 5V
Power: 1.5W
Bottle Capacity: 10 ml
G.W.: 220g
Consumption: 0.03-0.07 ml/h
Coverage: 10m²




Directions:



Grade	Working (s)	Stop(s)
G1	6	360
G2	6	180
G3	10	280
G4	10	140

Operation:



When change oil bottle, the vent hole of bottle should be right towards the gap of the body.


Car & Room Aroma Diffuser



Product: A601
Dimension: 70*133mm
Input Voltage: 5V
Power: 1.5W
Bottle Capacity: 10 ml
G.W.: 220g
Consumption: 0.03-0.07 ml/h
Coverage: 10m²




Directions:



Grade	Working (s)	Stop(s)
G1	6	360
G2	6	180
G3	10	280
G4	10	140

Operation:



When change oil bottle, the vent hole of bottle should be right towards the gap of the body.


Car & Room Aroma Diffuser



Product: A601
Dimension: 70*133mm
Input Voltage: 5V
Power: 1.5W
Bottle Capacity: 10 ml
G.W.: 220g
Consumption: 0.03-0.07 ml/h
Coverage: 10m²




Directions:



Grade	Working (s)	Stop(s)
G1	6	360
G2	6	180
G3	10	280
G4	10	140

Operation:



When change oil bottle, the vent hole of bottle should be right towards the gap of the body.