



How to Use Your Bonfire

Step 1

Remove the nested flame ring and set it aside.

Step 2

Using logs that are 16" or shorter, stack your logs tightly inside the Bonfire along with any kindling of your choice.

FOR BEST RESULTS, DO NOT OVERFILL THE BONFIRE WITH LOGS THAT COVER OR EXTEND ABOVE THE TOP AIR HOLES.


Step 3

Light your fire.

Step 4

Place the flame ring back on top of the Bonfire with the angled edges pointing upward.

THIS WILL PROVIDE PROTECTION FROM THE WIND AND ENHANCE THE LOOK OF THE FLAMES.



Step 5

Gently add additional logs as needed.

Step 6

Let the Bonfire to burn out on its own.

Step 7

After the Bonfire has completely cooled down, turn it over to empty any remaining ash.

Step 8

Place the Bonfire in its carrying case and store it in a cool and dry location.

Storage and Care

Caring for your Bonfire correctly will prolong its look and usability.

After each use, wait until the unit has completely cooled down then turn the Bonfire over to empty any remaining ash. If you want to wipe it down, use only a dry cloth.

Always place your Bonfire in its carrying case (which can also be used as a temporary outdoor cover) and store in a cool/dry location.

Due to extremely high temperatures, discoloration of the Bonfire will occur and is considered normal. Stainless steel has an increased resistance to rust; however, it is not rust-proof.

Prolonged exposure to moisture may result in increased staining and/or rusting. Due to extremely high temperatures inside of the Bonfire may show signs of staining/rust. This is normal and will not affect normal use.

Tips & Good Things to Know

- When you first use your Bonfire, the unique double-wall airflow within the unit will take approximately 5–15 minutes to achieve full efficiency. The more evenly your fire burns inside the Bonfire, the more prominent the flame pattern showing the secondary combustion will appear.
- Use dry hard woods for best results.
- Overfilling the Bonfire above the top air holes will decrease efficiency and will produce more smoke.
- Store your Bonfire in a cool and dry location. Prolonged exposure to harsh weather will increase rust and discoloration.

User Warnings

1. Solo Stove Bonfire is for outdoor use only and should not be used in a building, a garage, or any other enclosed area.
2. Solo Stove Bonfire will be extremely hot when in use. Never attempt to touch or move your Bonfire during use or before it has completely cooled down.
3. Do not use Solo Stove Bonfire for indoor heating. Toxic carbon monoxide can accumulate and cause asphyxiation and possibly death.
4. Solo Stove Bonfire is not for commercial use.
5. Solo Stove Bonfire is not to be operated by children. Solo Stove Bonfire is not a toy.
6. Never leave Solo Stove Bonfire unattended, especially when children and pets are nearby.
7. Solo Stove Bonfire is not to be used in a boat or recreational vehicle.
8. Always use Solo Stove Bonfire in accordance with all applicable local, state, and national codes. Contact your local fire department for details.
9. When using Solo Stove Bonfire, exercise the same precautions you would with any open fire.
10. The use of alcohol, prescription or non-prescription drugs may impair the consumer's ability to operate Solo Stove Bonfire safely.
11. Do not use Solo Stove Bonfire until you have read the operating instructions and user warnings.
12. Solo Stove Bonfire is designed for use with standard firewood logs and may not function properly with other fuel sources.
13. Do not alter or modify Solo Stove Bonfire in any manner.
14. Do not store or use gasoline or any other flammable vapors or liquids in the vicinity of Solo Stove Bonfire.
15. Do not store or use LP gas cylinders within 30 feet of Solo Stove Bonfire while it is in operation.
16. Do not use Solo Stove Bonfire near automobiles, trucks, vans, or recreational vehicles.
17. Do not use Solo Stove Bonfire in any explosive environment. Keep the area around the Solo Stove Bonfire clear and free of any combustible materials, gasoline, or any other flammable liquids.

Specifications

HEIGHT	DIAMETER
14"	19.5"
WEIGHT	MATERIALS
20lbs	304
	Premium Grade Stainless Steel

Suggested Fuel

Dry firewood logs

18. Do not use Solo Stove Bonfire under any overhead or near any unprotected combustible constructions. Avoid using under or near any overhanging trees or shrubs.
19. Always use Solo Stove Bonfire on a level non-combustible surface. Use on wood or composite decks at your own risk.
20. Do not wear flammable or loose clothing when operating Solo Stove Bonfire.
21. Do not use Solo Stove Bonfire in windy conditions.
22. Do not use gasoline, kerosene, diesel fuel, lighter fluid, alcohol or any other flammable liquid to light or relight Solo Stove Bonfire.
23. Keep all electrical cords away from Solo Stove Bonfire.
24. All surfaces of Solo Stove Bonfire are extremely hot when in operation. To avoid burns and serious injury, do not touch Solo Stove Bonfire until the fire is completely out and it has completely cooled. Never touch the coals or ash to see if they're still warm.
25. Do not attempt to move or store Solo Stove Bonfire until all fire, coals, and ashes are completely extinguished and the unit has completely cooled.
26. Do not remove any coals or ash or clean the fire pit until the coals and ash are completely extinguished and the unit has completely cooled.
27. Do not lean over Solo Stove Bonfire when lighting or when it is in use.
28. Avoid breathing smoke from the fire and avoid getting smoke in your eyes.
29. Solo Stove Bonfire should be inspected and cleaned regularly after each use.
30. After a period of non-use, check Solo Stove Bonfire for signs of damage and creosote buildup. Do not operate until necessary repairs and/or cleanup is done.
31. Do not use water to extinguish the fire as this could cause damage to the Bonfire as well as injury to the user.
32. Serious injury, death, and/or property damage may occur if the above instructions are not followed exactly.

FOR QUESTIONS OR COMMENTS, PLEASE VISIT SOLOSTOVE.COM OR EMAIL US AT HELP@SOLOSTOVE.COM.