



WWW.NKUKU.COM  
T:+44(0)1803 866847  
E:INFO@NKUKU.COM

---

## ASSEMBLY INSTRUCTIONS


## OBORO FILM LIGHT

Thank you for purchasing this Oboro Film Light.  
Please read the instructions carefully before use to ensure safe and satisfactory  
operation of this product. Please keep these instructions for future reference.

## FIXING INSTRUCTIONS

The following items should make up your Oboro Film Light:

- PART A - 1 x Tripod Base Stand
- PART B - 1 x Centre Bar
- PART C - 1 x Lamp



### STEP 1

Open out the Tripod Base (PART A) and secure by tightening the screw. **Ensure the tripod legs are extended to the maximum width to give maximum stability.**

### STEP 2

Insert the Centre Bar (PART B) into the Tripod Base (PART A)

### STEP 3

Place the Lamp (PART C) onto the Centre Bar and tighten the screw to secure.

### ADJUSTMENTS

Adjust the height by raising or lowering the Centre Bar in the Tripod Base and tighten using the screw at the top of the tripod base. Adjust the angle of the lamp by loosening the screw at the back of the lamp and re-tightening at the required angle.

### CARE AND CLEANING

Finish - We recommend cleaning with a soft dry cloth. Do not use abrasive materials as these will damage the finish.

### SAFETY INFORMATION

For your safety, always switch off the supply before changing light bulbs or cleaning.

### FITTING/ REPLACING THE BULB

Bulb Type - 60 W Max bulb. When changing a bulb, always switch off at the mains and allow the bulb to cool before handling. Dispose of used bulbs carefully. Do not exceed the wattage stated.

### INDOOR USE ONLY