

boat



THE SOUND OF SLICK



Airdopes 101 True Wireless Ear-buds

Airdopes 101 True Wireless Ear-buds

Get ready to immerse yourself in musical bliss with your very own pair of boAt Airdopes 101. Please consider this manual as your guiding map towards the unparalleled shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual; also, you may refer to the same at times when you face any sort of difficulty in future.

Package Contents

- 1x boAt Airdopes 101
- 1x Charging Case
- 1x Type-C Charging Cable
- 2x Pairs of Additional Earbuds (Small & Large)
- 1x User Manual
- 1x Warranty Card
- 1x Catalogue

Overview

- 1. CTC (Capacitive Touch Control) / Power Button



Power On:

Step 1: To switch the earbuds on Smart Power On, simply open the lid of the charging case when earbuds are inside. Our Tap™ (Touch, Voice & Tap) Technology enables the earbuds to power on automatically, get connected and enter into the connection mode.

OR

Step 2: Both the earbuds will automatically pair with each other. The earbuds will enter into the Connection Mode, indicated by red and blue LED flashes.



Connection Mode:

Step 3: Turn on the Bluetooth functionality on your phone/media device and scan.

Step 4: Search for Airdopes 101 and pair accordingly.


Congratulations! Your earbuds are now connected successfully via Bluetooth.

Notes:

- Pairing mode lasts for 5 minutes. If the pairing time is missed then you will need to reconnect the earbuds and follow the above mentioned procedure.
- Airdopes 101 remembers previously connected devices; once switched on, the earbuds automatically reconnect to the previously connected devices.



LED Indicators / Functionalities



Single Earbud Usage

Step 1: Please note that both the earbuds can be used in mono mode. Use Smart Manual Power On for switching on the desired earbud.

Step 2: The selected earbud will automatically enter the connection mode indicated by red and blue LED flashes.

Step 3: Touch on Bluetooth on your phone/media device and search for Airdopes 101 to connect.

Notes:

- To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud. Hence enabling Stereo usage.
- You cannot skip tracks or return to the previous tracks in Mono mode.



Charge the Earbuds:

Step 1: Please insert the earbuds back inside the charging case in correct orientation.

Step 2: If red led LED indicates that the earbuds are being charged. Once fully charged the LED turns off.

Step 3: Once the earbuds are fully charged, the charging case automatically switches off to save power.

Note:
- Before using the ear buds for the first time, it is recommended to fully charge the ear buds. Also, please keep the lid of the charging case closed while charging.

Charge The Case:

Warning: Please do not charge the carry case with "9V" or "12V" output. Otherwise, it may cause damage to the case. Charge only according to the charging norms (not more than 5V 2A).

Step: To charge the case, plug one end of the provided cable into the case and connect the other end to a computer/wall adapter/powerbank, etc.

Recharging Case Battery Indicator
0-50%: Red
50-100%: Green



Basic Functions:

- **Voice Assistant:** Long touch the CTC on either earbud for 2 seconds to activate the voice assistant.

- **Answer/Hang Up Call:** Single tap the CTC on either earbud to answer an incoming call and one again to hang up an ongoing call.

- **Reject Call:** Long touch the CTC for up to 1.5 seconds to reject incoming calls.

- **Play/Pause Music:** Single tap on either earbud's CTC to play or pause music.

- **Next Track:** When playing music, double tap the right CTC to skip to the next song.

- **Previous Track:** When playing music, double tap the left CTC to return to the previous song.

Note:
- Volume can only be controlled via the media device.




Voice Assistant:

Step 1: Long touch the CTC on either earbud for 2 seconds to activate the smart voice assistant.

Step 2: The respective voice assistant screen pops up and you may place your commands at ease.

Tips: You may try the following commands,

- What is the weather? (Play a song)
- Set a reminder



Smart Power Off

Step 1: After usage, remove both the earbuds from your ears.

Step 2: Place the earbuds back into the charging case in correct orientation and close the lid.

Step 3: The earbuds will automatically switch off (and enter into charging mode).



Factory Reset:

Perform the Factory Reset in case you face any difficulty while operating your Airdopes 101.

***NOTE:** Before performing reset, clear "Airdopes 101" from pairing device history by forgetting device.

Step 1: Place both the earbuds back inside the charging case in correct orientation and close the lid.

Step 2: Take out both the earbuds from the case and triple tap on both CTCs (outside the case) to do Factory reset, which is indicated by the red LED.

Step 3: Keep them back inside the case and shut the lid; after a few seconds re-open it again.

Step 4: Once you take the earbuds out from the charging case, the Reset gets completed.

Step 5: Congratulations! Your Airdopes 101 has been reset.



Manual Power Off

Step 1: Long touch the CTC on either earbud for 5 seconds.

Step 2: Once the earbuds get turned off, place them back inside the case and close the lid.

Specifications

Bluetooth Version	V5.0
IPX Technology	Yes
Music Playtime	Up to 3H per charge; Up to 12H additional with Case
Standby Time	102H
Transmission Range	10m
Driver Size	13mm*2
Bluetooth Profiles	HSP, HFP, A2DP, AVRCP
Frequency	2400-2480MHz
Battery	60mAh (Case) 40mAh*2 (Earbuds)
Charging Time	2H
Charging Interface	Type C
Product Weight	7.48g

Charging norms & Precautionary Guidelines:

- 1) Charger/Brick/Adapter
 - 2) Cable/Wire
- 5V 3A
Standard Cable (35 strands)
Ø1.0mm diameter strands

Any other accessory can be paired up with this product as long as the specifications are as per above norms.

Troubleshooting

Potential Problem	Solution
If earbuds are not working	Check the battery level
If earbuds are not in connection mode	Perform the Factory Reset
If earbuds do not connect to phone call	Charge the earbuds or perform the Factory Reset
If case is not accepting to charge	Place the earbuds back into the charging case and try to fully charge or perform the Factory Reset
If touch controls don't seem to respond	After long usage, earbuds cases & earbuds may get hot. Cool them down and try again. Also, clean the touch sensor area. Make sure there is no liquid on the touch sensor area.

Warning:

- Please follow the instructions to operate.
- Please don't use the ear buds in extreme temperatures.
- Please don't use the product near water.
- Please keep the product away from heat sources, as the heat may damage it.
- Clean from the ports such as charger port, LED port, etc.
- It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the ear buds' service life.

Advice: The earbuds start at a 100% volume and it may need to be reduced when the earbuds are switched on at first. This can be done by using the phone / media device.