



Airdopes 111

True Wireless Ear-buds

Get ready to immerse yourself in musical bliss with your very own pair of boAt Airdopes 111. Please consider this manual as your guiding map towards the unparalleled shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual; also, you may refer to the same at times when you face any sort of difficulty in future.

Package Contents

- 1x boAt Airdopes 111
- 1x Charging Case
- 1x Type-C Charging Cable
- 2x Pairs of Additional Earmuffs (Small & Large)
- 1x User Manual
- 1x Warranty Card
- 1x Catalogue

Overview

- 1. CTC (Capacitive Touch Control) / Power Button




Power On:

Step 1: To switch the earbuds on Smart Power On, simply open the lid of the charging case when earbuds are inside. Our Tap™ (Touch, Wake & Pair) Technology enables the earbuds to power on automatically, get connected and enter into the connection mode.

OR

Step 2: After powering on, the earbuds enter into the Connection Mode, indicated by red and blue LED flashes.



Connection Mode:

Step 3: Turn on the Bluetooth functionality on your phone/media device and scan.

Step 4: Search for Airdopes 111 and pair accordingly.


Congratulations! Your earbuds are now connected successfully via Bluetooth.

Note:

- Pairing mode lasts for 5 minutes. If the pairing time is missed then you will need to re-initiate the ear buds and follow the above mentioned procedure.
- Airdopes 111 remembers previously connected devices; once powered on, the ear buds automatically reconnect to the previously connected devices.



LED Indicators / Functionalities



Single Earbud Usage

Step 1: Please note that both the earbuds can be used in mono mode. Use Smart Manual Power On for switching on the desired earbud.

Step 2: The selected earbud will automatically enter the connection mode indicated by red and blue LED flashes.

Step 3: Touch on Bluetooth on your phone/media device and search for Airdopes 111 to connect.

Note:

- To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud. Hence enabling Stereo usage.
- You cannot skip tracks or return to the previous tracks in Mono mode.



Charge the Earbuds:

Step 1: Please insert the earbuds back inside the charging case in correct orientation.

Step 2: When red LED on earbuds indicates that the earbuds are being charged. Once fully charged the LED turns off.

Step 3: Once the earbuds are fully charged, the charging case automatically indicates off to and power.

Note:

- Before using the ear-buds for the first time, it is recommended to fully-charge the ear buds. Also, please keep the lid of the charging case closed while charging.
- If battery is 20% or below then the red LED blinks every five seconds to indicate low battery.

Charge The Case:

Step 1: To charge the case, plug one end of the provided cable into the case and connect the other end to a computer, wall adapter, powerbank, etc.

Note:

- Red LED flashes while the case is on charging. When the charge gets full, it gets indicated by solid red LED.



Basic Functions:

- **Voice Assistant:** Long touch the CTC on either earbud for 3 seconds to activate the voice assistant.

- **Answer:** Single tap the CTC on either earbud to answer an incoming call.

- **Hang Up / Reject Call:** Double tap the CTC on either earbud to end or reject call.

- **Play/Pause Music:** Single tap on either earbud's CTC to play or pause music.

- **Next Track:** When playing music, double tap the right CTC to skip to the next song.

- **Previous Track:** When playing music, double tap the left CTC to return to the previous song.

Note:

- Volume can only be controlled via the media device.




Voice Assistant:

Step 1: Long touch the CTC on either earbud for 3 seconds to activate the smart voice assistant.

Step 2: The respective voice assistant screen pops up and you may place your commands at ease.

Tips: You may try the following commands,

- What is the weather?
- Play a song
- Set a reminder



Smart Power Off

Step 1: After usage, remove both the earbuds from your ears.

Step 2: Place the earbuds back into the charging case in correct orientation and close the lid.

The earbuds will automatically switch off and enter into charging mode.



Factory Reset:

Perform the Factory Reset in case you face any difficulty while operating your Airdopes 111.

Note: Before performing reset, clear "Airdopes 111" from pairing device history by forgetting device.

Step 1: Take out the earbuds from the charging case, and long touch the CTC for 5 seconds on both the earbuds, indicated by LED flashes 5 times.

Step 2: Place the Earbuds back inside the case, close the lid and wait for 5 sec.

Step 3: Take out the earbuds from the charging case and perform a fresh connection.

Step 4: Congratulations! Your Airdopes 111 has been reset.



Manual Power Off

Step 1: Long touch both CTCs for 5 seconds to manually power off.

Step 2: Once the earbuds get turned off, place them back inside the case and close the lid.

Specifications

Bluetooth Version	V5.1
IPX Technology	Yes
Music Playtime	Up to 7H per Charge Up to 2.1H additional with Case
Talk Time	10H
Transmission Range	10m
Driver Size	13mm*2
Bluetooth Profiles	AVRCP, A2DP, HFP, HSP, AVRCP
Frequency	20Hz-20KHz
Battery	150mAh (Case) 40mAh*2 (Earbuds)
Earbuds Charging Time	1H
Case Charging Time	1.5H
Charging Interface	Type C
Product Weight	Earbuds: 2*3.8g, Case: 46.6g

Charging norms & Precautionary Guidelines:

- 1) Charger/Brick Adapter: 5V 2A
- 2) Cable/Wire: Standard Cable (3.5 strands, 10m diameter) (standard)

Any other accessory can be paired up with the product as long as the specifications are as per device norms.

Troubleshooting

Potential Problem	Solution
If earbuds are not working	Re-check the device battery
If earbuds are not in connection mode	Perform the Factory Reset
If earbuds do not answer incoming call	Change the earbuds or perform the Factory Reset
If there are other accessories in usage	Place the earbuds back into the charging case and try to pair them again or perform the Factory Reset
If Touch Controls don't seem to respond	Also long touch earbuds cases & perform reset, use after the touch control case, when there is case closed to make them area ready

Warning:

- Please follow the instructions to operate.
- Please don't use the ear buds in extreme temperatures.
- Please don't use the product near water.
- Please keep the product away from heat sources, or the heat may damage it.
- Check from the ports such as charger port, LED port, etc.
- It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the ear buds' service life.

Advice: The earbuds start at a 100% volume and it may need to be reduced when the earbuds are switched on at first. This can be done by using the phone / media device.