


Get ready to immerse yourself in musical bliss with your very own pair of boAt Airdopes 192. Please consider this manual as your guiding map towards the unparalleled shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual. Also, you may refer to the same at times when you face any sort of difficulty.

PACKAGE CONTENTS

- 1) 1x Pair of TWS Earbuds
- 2) 1x Type-C Charging Cable
- 3) 2x Pair of Extra Earmuffs
- 4) 1x FAQ Card
- 5) 1x Charging Case
- 6) 1x User Manual
- 7) Warranty Card
- 8) Catalogue

OVERVIEW

- 1) CTC (Capacitive Touch Control) / Power Button




POWER ON (FIRST TIME USER):

Step 1: To switch the earbuds on (Smart Power On) simply open the lid of the charging case (when earbuds are inside). Courtesy our IWP™ (Insta Wake N' Pair) technology, the earbuds power on automatically, get connected and enter the connection mode

OR

Long touch the CTC (Capacitive Touch Control) on both earbuds for 3 seconds to manually power on the earbuds

Step 2: After powering on, the earbuds enter the Connection Mode, indicated by alternate red and blue LED flashes on primary earbud



CONNECTION MODE:

Step 3: Turn on the Bluetooth functionality on your phone/media device and scan
Step 4: Search for 'Airdopes 192' and pair accordingly. Congratulations! Your earbuds are now connected successfully via Bluetooth

Note :


• Pairing mode lasts for 3 minutes. If the pairing time is missed then you will need to reconnect the ear-buds and follow the above mentioned procedure

• Airdopes 192 remembers previously connected devices; once switched on, the ear-buds automatically reconnect to the previously connected devices



QUICK GLANCE ON FUNCTIONALITIES

- 3 Seconds: Long touch left CTC for 3 sec to activate voice assistant
- 3 Seconds: Long touch both CTCs for 3 seconds to manually power on
- 5 Seconds: Long touch both CTCs for 5 seconds to manually power off
- 5 Seconds: Long touch both CTCs for 5 seconds to perform factory reset



SINGLE EARBUD USAGE

Step 1: Please note that both the earbuds can be used in mono mode. Use Smart / Manual Power On for switching on the desired earbud

Step 2: The selected earbud will automatically enter the connection mode indicated by red and blue LED flashes

Step 3: Turn on Bluetooth on your phone/media device and search for 'Airdopes 192' to connect

Notes:

- To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, hence enabling Stereo usage
- You cannot skip tracks or return to the previous tracks in Mono (single-earbud) mode

CHARGING THE EARBUDS

Step 1: Please insert the earbuds back inside the charging case in correct orientation and close the lid.

Step 2: During charging whenever the lid gets closed, LEDs are turned on to indicate that both left and right earbuds are getting charged respectively.

Step 3: Once the earbuds get fully charged, the charging case automatically switches off to save power

Notes:
 • Before using the earbuds for the first time, it is recommended to fully charge the earbuds. Also, please keep the lid of the charging case closed while charging.

CHARGE THE CASE:

Step: To charge the case, plug one end of the provided cable into the case and connect the other end to a computer/wall adapter/power bank, etc.

While the case is on charging, led flashes depending on the total remaining case battery. When the case gets fully charged, it gets indicated by Solid LED.



Charging norms & Precautionary Guidelines:-

- 1) Charger/Brick/ Adapter : 5V 2A
 - 2) Cable/Wire : Standard Cable (35 strands @0.10mm diameter/ strand)
- Any other accessory can be paired up with the product as long as the specifications are as per above norms.

BASIC FUNCTIONS

- **Voice Assistant:** Long touch the left CTC for 3 seconds to activate the voice assistant.
- **Answer:** Single tap CTC on either earbud to answer an incoming call.
- **Hang Up / Reject Call:** Double tap the CTC on either earbud to end / reject call.
- **Play/Pause Music:** Single tap either earbud's CTC to play or pause music.
- **Next Track:** When playing music, double tap the right earbud's CTC to skip to the next song.
- **Previous Track:** When playing music, double tap the left earbud's CTC to return to the previous song.

Note: Volume can only be controlled via the media device

BEAST™ MODE

Long touch the right CTC for 3 seconds to switch to Low Latency mode, also known as the BEAST™ Mode. Once switched on, it gets notified via a sound prompt. Long touch the right CTC for 3 seconds once again, to turn it off and return to standard Music Mode.

Made for the Gamers - By Gamers, BEAST™ Mode reduces the latency significantly and improves the overall gaming experience.

ENx™ TECH

Our ENx™ (Environmental Noise Cancellation) tech algorithm cancels out the background noise so that you can hear crystal clear via voice calls. One need not activate ENx™ as the 4x mics are already equipped with the same and activated by default.

Deliver your voice without interruptions anywhere - traffic, railway stations, airports, work space; literally anywhere!


VOICE ASSISTANT:

Step 1: Long touch the CTC on left earbud for 3 seconds to activate the smart voice assistant.

Step 2: The respective voice assistant screen pops up and you may place your commands at ease.

Tips: You may try the following commands,

- What is the weather?
- Play a song
- Set a reminder



Note: If the voice assistant doesn't get triggered, then the functionality has to be first enabled via your media device settings.

SMART POWER OFF

Step 1: After usage, remove both the earbuds from your ears.

Step 2: Place the earbuds back into the charging case in correct orientation and close the lid.

The earbuds automatically switch off (and enter charging mode).



MANUAL POWER OFF

Step 1: Long touch both CTCs for 5 seconds (one at a time) to manually power off the earbuds.

Step 2: Once the earbuds get turned off, place them back inside the case and close the lid.

FACTORY RESET:

Perform the factory reset in case you feel any difficulty while operating your Airdopes.

*NOTE: Before performing reset, clear "Airdopes 192" from pairing device history by forgetting device

Step 1: Take out both the earbuds from the case

Step 2: Long touch CTC on both the earbuds for 5 seconds; LED flashes quickly for 5 times

Step 3: Place the earbuds inside the case, close the lid and wait for 5 seconds

Step 4: Take out the earbuds from the case and perform a fresh connection

Congratulations! Your Airdopes 192 has been Reset



SPECIFICATIONS

Headphone Type	TWS
Music Playtime	Up to 10HRS per charge; Up to 20HRS additional with Case (at 60% volume)
Bluetooth Version	V5.3
ENx™ Equipped Mics	4
IWP™ Tech	Yes
BEAST™ Mode	Yes; 40ms Super Low Latency
Transmission Range	10m
Driver Size	13mm Gaming Grade Drivers
Supported Codec	AAC/SBC
Frequency	20HZ-20KHZ
Battery	300mAh (Case) 30mAh*2 (Earbuds)
Charging Time	30mins - 45mins (Earbuds) ; Up to 1.5H (Case)
Charging Interface	USB Type C
Water Resistance	IPX4

WARNING:

- Please follow the instructions to operate
- Please don't use the ear-buds in extreme temperatures
- Please don't use the product near water
- Please keep the product away from heat sources, as the heat may damage it
- Don't jam the ports such as charger port, LED port, etc.
- It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the ear-buds' service life

Advisable: The earbuds start at a 100% volume and it may need to be reduced when the earbuds are switched on at first. This can be done by using the phone / media device

