

# Airdopes 452

## STEP UP

Airdopes 452

Get ready to immerse yourself in musical bliss with your very own pair of boAt Airdopes 452. Please consider this manual as your guiding map towards the unparalleled shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual also, you may refer to the same at times when you face any sort of difficulty in future.

### In the box

- 1x Pair of TWS Earbuds
- 1x Charging Case
- 1x Catalogue
- 1x User Manual
- 1x Type-C Charging Cable
- 1x FAQ Card
- 1x Warranty Card
- 1x Read Me Card

### Power On (First Time User)

**Step 1:** To switch the earbuds on (Smart Power On) simply open the lid of the charging case. When earbuds are inside, our iAP™ (Intelligent Wake Up) Technology enables the earbuds to power on automatically, get connected and enter into the connection mode.

OR

Long touch the CTC on both earbuds for 3 seconds to manually power on the earbuds (indicated by solid white LED for 1 second).

**Step 2:** Both the earbuds will automatically pair with each other. The earbuds will enter into the Connection Mode, indicated by rapid white LED flashes.

**Connection Mode**

**Step 3:** Turn on the Bluetooth functionality on your phone/media device and scan.

**Step 4:** Search for Airdopes 452 and pair accordingly.

Congratulations! Your earbuds are now connected successfully via Bluetooth.

**Note:**

\* Pairing Mode lasts for 5 minutes. If the pairing time is missed then you will need to reconnect the earbuds and follow the above mentioned procedure.  
\* Subsequent usage: Airdopes 452 reconnects previously connected device, once switched on, the earbuds automatically reconnect to the previously connected device.



### Single Earbud Usage

**Step 1:** Please note that both the earbuds can be used in mono mode. Use Smart / Manual Power On for switching on the desired earbud.

**Step 2:** The selected earbud will automatically enter the connection mode, indicated by rapid white LED flashes.

**Step 3:** Turn on Bluetooth on your phone/media device and search for Airdopes 452 to connect.

**Notes:**

- To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, hence enabling Stereo usage.
- You cannot skip tracks or return to the previous tracks in Mono mode.



### LED Indicators / Functionalities

Long touch left CTC for 3 sec to activate voice assistant.

3 Seconds

Long touch both CTCs for 3 seconds to manually power on, indicated by white LED flash for 1 second.

3 Seconds

Long touch both CTCs for 8 seconds to manually power off, indicated by white LED flash for 1 second.

8 Seconds

Long press the Reset Button on the case for up to 10 seconds for the factory reset, indicated by 3 white LED flashes on the case as well as the earbuds.

10 Seconds



### CHARGING THE EARBUDS/ EARBUD INDICATORS

**Step 1:** Please insert the earbuds back inside the charging case in correct orientation and close the case lid.

Once the earbuds are fully charged, the charging case automatically switches off to save power.

**Note:**

- Before using the ear-buds for the first time, it is recommended to fully charge the ear-buds. Also, please keep the lid of the charging case closed while charging.
- If the earbuds have battery lower than 20%, white LED blinks thrice every 30 seconds.

Case	Normal State (Not in Charging State)
Case 1 – Low battery in 0/ remaining battery in 10; less than 20%.	WHITE LED blinks (3 times) on opening the lid.
Case 2 – More than 70% charge.	WHITE LED solid (for 3 seconds) on opening the lid.

Case	Charging State
Earbuds – charging	White LED Solid (2 seconds) on opening the lid.
Earbuds – Full charged	LED OFF

### Charge The Case

**Step:** To charge the case, plug one end of the provided cable into the case and connect the other end to a computer/ wall adapter/ powerbank, etc. While the case gets charged it gets indicated by slow breathing white LED. Whereas when it gets fully charged, the LED turns into solid white.

### Basic Functions

- Voice Assistant: Long touch the CTC on left earbud for 3 seconds to activate the voice assistant.
- Answer Call: Single tap the CTC on either earbud to answer an incoming call.
- Hang Up Call: Double tap the CTC on either earbud.
- Reject Call: Double tap the CTC on either earbud.
- Play/Pause Music: Single tap on either earbud's CTC to play or pause music.
- Next Track: When playing music, double tap the right CTC to skip to the next song.
- Previous Track: When playing music, double tap the left CTC to return to the previous song.

### Basic Functions

- BEAST™ Mode: Long touch the right earbud's CTC for 3 seconds to switch to Low Latency mode infused with Virtual 3D Sound, also known as the BEAST™ Mode. Made for the Gamers. By Gamers. BEAST™ Mode reduces the latency significantly and improves the overall gaming experience. With BEAST™ mode, the earbuds activate 3D audio mode especially made for gaming.

To turn off the BEAST™ mode and return to Standard mode, long touch the right earbud's CTC for another 3 seconds.

**Note:**

\* Volume can only be controlled via the media device or Triple tapping the CTC.

- Triple tap right earbud - Volume up
- Triple tap left earbud - Volume down



### Voice Assistant

**Step 1:** Long touch the CTC on left earbud for 3 seconds to activate the smart voice assistant.

**Step 2:** The respective voice assistant screen pops up and you may place your commands at ease.

**Tips:** You may try the following commands.

- What is the weather?
- Play a song
- Set a reminder



### Smart Power Off

**Step 1:** After usage, remove both the earbuds from your ears.

**Step 2:** Place the earbuds back into the charging case in correct orientation and close the case lid.

**Step 3:** The earbuds will automatically switch off (and enter into charging mode).

### Manual Power Off

**Step 1:** Long touch the CTC on both earbuds for 8 seconds.

**Step 2:** Once the earbuds get turned off, place them back inside the case and close the lid.



### Factory Reset

Perform the Factory Reset in case you face any difficulty while operating your Airdopes 452.

**\*NOTE:** before performing reset, clear "Airdopes 452" from pairing device history by forgetting device.

**Step 1:** Place both the earbuds back inside the charging case in correct orientation.

**Step 2:** While the earbuds are inside the case let the charging case lid remain open, long press the Reset button located outside the case for 10 seconds, until the white LED blinks on the earbuds as well as the case.

**Step 3:** Close the case lid and then reopen it again.

Congratulations! Your Airdopes 452 has been Reset, now you may perform a fresh pairing procedure to establish connection.



### Troubleshooting

Potential Problem	Solution
If one earbud is not working	Perform the Factory Reset
If earbuds are not in connection/ scan mode	Perform the Factory Reset
If earbuds disconnect during phone call	Charge the earbuds or perform the Factory Reset
If there are other exceptions in usage	Place the earbuds back into the charging case and try using them again or perform the factory Reset
If Touch Controls don't seem to respond	After long usage, residual stains and perspiration can affect the touch control area, please use a clean cloth to wipe these areas softly

### Charging norms & Precautionary Guidelines:

1) Charger/Back/Adapter	:5V/2A
1) Cable/Wire	:Standard Cable (35 Strands 10) (10mm diameter/strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.


### Specifications

Headphone Type	TWS Earbuds
Bluetooth Version	V5.2
Water Resistance	IPX4
TWS Technology	Yes
No. of Mics	1 per Earbud
ASAP Charge	Yes
Music Playtime	Total 20HRS (Case: 4xCharge); Earbuds 4HRS
BEAST Mode™	Yes
Transmission Range	10m
Driver Size	6mm*2
Bluetooth Profiles	HFP/ HSP/ A2DP/ AVRCP
Frequency	20Hz-20KHz
Battery	30mAh (Case) 40mAh*2 (Earbuds)
Charging Time	50Min Earbuds
Standby Time	9 months
Charging Interface	Type-C
Product Weight	Earbuds 4g*2; Case 50g

### Warning

- Please follow the instructions to operate
- Please don't use the ear-buds in extreme temperatures
- Please don't use the product near water
- Please keep the product away from heat sources, as the heat may damage it
- Don't jam the ports such as charger port, LED port, etc.
- It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the ear-buds' service life.

Advisable: The earbuds start at a 100% volume and it may need to be reduced when the earbuds are switched on at first. This can be done by using the phone / media device.



Airdopes 452