



Aavante Bar Aspire

Thank you for choosing Aavante Bar Aspire. You are now just a step away from the realm of pure audio bliss. With the Aavante Bar Aspire, experience immersive, cinematic audio on a whole new level at home. Stay plugged into the sound with an array of Aux, USB, and Bluetooth wireless technology. Bring your home to life with the boAt "Aavante Bar Aspire". Allow this manual to guide you through the functioning of your sound system.

PACKAGE CONTAINS:

1X Wireless Soundbar
1X USB Type-C Charging Cable
1X Audio Cable

1X User Manual 1X Warranty Card 1X Catalogue

SAFETY & WARNING

IMPORTANT SAFETY INSTRUCTIONS

- 1. Read these instructions. Keep these instructions. Follow all instructions. Heed all warnings.
- 2. Do not use the device near water.
- 3. Clean only with a dry cloth.
- 4. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 5. Do not install near any heat sources such as radiators, heaters, stoves, or other devices (including amplifiers) that produce heat.
- 6. Do not ignore the safety measures of a polarized or grounding-type plug. A polarized plug has two blades, one wider than the other.
- 7. Pay special attention to the positioning of cords, plugs, and power sockets, especially the point where they exit from the unit.
- 8. Only use attachments/accessories specified by the manufacturer.
- 9. Unplug this apparatus during lightning storms or when not in use.
- 10. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damage in any way, for example, when the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

USER MANUAL

PRODUCT OVERVIEW SOUNDBAR CONTROL PANEL:



- 1. Play/Pause Button:
- In BT/USB and AUX mode, short press the button to play/pause the sound.
- \bullet To reset the Bluetooth History Long Press Play/Pause Button for 3 Seconds.
- 2. Volume Decrease/Previous Track: Short press in steps to reduce the master volume, and long press to go back to the previous track. Blue LED will flash in Bluetooth mode.
- 3. Volume Increase/Next Track: Short press in steps to increase the master volume & long press to skip to the next track.
- 4. Mode (MFB) Button: Short press to turn to BT/USB/Aux mode/FM.



1. Power Toggle Button – Toggle Right to power on the device. The default mode will be Bluetooth mode. The device will immediately go into pairing mode. The Bluetooth pairing name will be Aavante Bar Aspire. Once paired successfully, the LED will be solid blue.

- 2. Aux Port Connect provided Aux Cable here.
- 3. TF Card Slot Insert the TF Card here.
- 4. Charging Port Slot Insert provided Charging Cable here.
- 5. USB Slot Please insert a pen drive over here. (Supports up to 32 GB)
- 6. Charging LED Indicator When the device is charging the LED will glow in red color & the LED will go off once the device is fully charged.

BLUETOOTH PAIRING

- 1. Turn the soundbar on. (By default, Bluetooth mode gets switched on)
- 2. Activate your media device's Bluetooth functionality and search "Aavante Bar Aspire" and as soon as it gets selected by you and paired, music can be played wirelessly.
- 3. Under Bluetooth mode, single press Play/Pause button to answer & hang up the call. Long press Play/Pause button to reject the call.
- 4. To Reset the Bluetooth History Long Press Play/Pause Button for 3 Second.

Note:

The soundbar can automatically reconnect to the last paired device whenever switched on in the BT mode.

USING THE SOUNDBAR

AUX/USB/FM MODES: Turn on the soundbar and switch it to the desired mode. Connect it with the respective mode (AUX/USB/FM) and start the playback.

TWS CONNECTION

- 1. Turn on the two Aavante Bar Aspire which you require to be paired together.
- 2. You only have to set up one of the two devices.
- 3. Instant Double click the Play/Pause button on one of the devices and the Bars will pair together within 5 seconds.
- 4. You will hear a voice prompt for the same. You can finally connect the speaker to your mobile device by searching for "Aavante Bar Aspire".

FM MODE

- Insert the charging cable or aux cable into the slot for an external antenna to enhance the signal.
- Press the "M" button to enter the FM mode.
- Press the "Play/Pause" button to search channels automatically.

CHARGING

- Connect one end of the provided charging cable to the charging input and the other end to a standard 5V/2A adapter.
- While getting charged, the LED stays red. Once the speaker gets fully charged, the LED turns off.

SPECIFICATIONS:

Model	boAt Aavante Bar Aspire
Bluetooth Version:	V5.1
Net Weight:	650 gram
Working Range:	10m
Driver Size:	2"*2
Compatibility	Bluetooth, AUX, USB
Frequency:	50hz-16Khz
Input Voltage:	DC 5V/2A
Output Power:	5W*2