



boat
COSMOS

Thank you for choosing the boAt Cosmos as your fitness transformation companion.

Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as well.




PACKAGE CONTAINS:
• boAt Cosmos x1
• USB magnetic charging cable x1
• User Manual x1
• Warranty Card x1

CHARGING THE WATCH

The smartwatch must be charged before initial use. It takes 30 minutes to be fully charged. Connect and charge the watch with the image below as a reference, using a 5V/2A adapter.

Note: Once your watch is at 10% battery, it will automatically switch to power saving mode which will disable all functions.



TURNING THE WATCH ON/OFF

To turn the watch on/off, long-press the side button for 3-5 seconds.

You can wake the screen by lifting your wrist. Enable it from the app to use.

CONNECTING TO THE APP

1. Download the boAt Crest app on your phone.

Available on both App Store (iOS 13.0 and above) and Google Play Store (Android 7.0 and above)

OR

Scan [QR CODE] (Also available on the watch)

2. Connect the device directly with the mobile application.

3. Select COSMOS on the home screen of the app and click OK to connect.

5. Turn your phone's Bluetooth and GPS on.

6. Disable battery optimization

Note: To ensure connectivity throughout your journey, make sure the app is allowed to run in the background of your phone at all times.



Activities

Your watch is equipped with 20 default activities from Walking, Treadmill, Running, Badminton, Football, Basketball, Tennis, Yoga, Dancing, Indoor Cycling, Cricket, Boxing, Karate, Table Tennis, Pilates, Skipping, Hiking, Hockey, Kabaddi, Bowling

You also get an array of activity mode options on the app which you can select and push to the watch.

The steps to use them are as follows:

1. Make sure your watch and app are connected. Also ensure any existing activity record on the watch is already synced to the app.

2. Select the activity category of interest

3. The screen will show you the list of activities within the category. Further select the activity within this category which you want to push to the watch.

4. You can also search for an activity from the search box.

5. Next, select the activity you want to replace.

6. Once you confirm, it will be available on your watch for use! To pause or stop the exercise, press the home button.

Note: To ensure connectivity throughout your journey, make sure the app is allowed to run in the background of your phone at all times.

*Note: *All records will be available on the app if you keep it synchronized.*

Activity Records

Tap on this icon to check sports records.



Heart Rate Monitor

Wear the watch on your wrist, then click on the measure button to start measurements. You can also view the data on the app.

Note: Measurements are for reference only and not for medical purposes.



Blood Oxygen Level Monitor

Wear the watch on your wrist, then click on the measure button to start measurements. You can also view the data on the app.

Note: Measurements are for reference only and not for medical purposes. Make sure you are in a still position for accurate results



Sleep Monitor

Tap on the icon to review the sleep data of the previous night. Once the asleep criteria is met, your wave Cosmos will start recording from 8 pm at night to 10 am in the morning the next day.

Once you lie down and watch detects no movement for 30 minutes, it will start recording, and will stop recording if it detects excessive movement.

You can check the data on the app only after the awake criteria is met. You can also track sleep scores on the boAt Crest app.

*Note: *For accurate sleep data recording, the asleep criteria has to be met which includes limited movement, wrist positions and angles, and more. *The awake criteria will be met only after it records some noticeable movement.*



Breathing exercises

Click on the breath training icon to regulate your breathing with the instructions given to relax.


Note: Measurements are for reference only and not for medical purposes.



Notifications


Turn this feature on from your app to receive notifications on your watch. You can also send quick replies on an incoming call or SMS notification.

Note: The watch can be used to reject calls only. Quick replies will work only with call and SMS notifications..



Stopwatch

Tap on the icon to start the stopwatch.



Timer

Tap on this icon to start the timer.



Alarm

Tap on this icon to set alarms.



Flashlight


Tap on this icon to turn your screen into the flashlight.



Camera Control

Click on the remote camera icon on your Cosmos to click a photo from your phone.


Note: Turn the camera on from your app to use this feature.



Music Control

Tap on this icon to launch music control mode.

Note: Ensure the music App is running on your phone for this feature to work properly. This feature might not work for some of the Music Apps with different control protocols.



Weather

Enable this feature from the app to track the weather forecast for next 6 days. You can also track humidity, wind speed and air pressure for the current day.



Find My Phone

Tap on this icon to find your phone. Once enabled, your phone will start ringing and vibrating. Tap again to stop it.

Note: Your Cosmos should be connected to your phone via Bluetooth and within its range for this feature to work.



Settings

Display

Watch Faces

Tap on this icon to change your watch face.



Screen sleep

Tap on this icon to set screen timeout duration.




Vibration

Set your preferred vibration intensity for your watch.



Do Not Disturb

This will disable all notifications except for alarms and alerts.



Restart

Tap on this to restart your watch.




Power off

Tap on this to switch your watch off.



Reset

Tap on this to reset watch data.



**Note: All data will be erased if watch is reset*

Download app

Tap on this icon to download the app through QR code.



About

Tap on this icon to view information about the watch.




Swipe down for shortcut menu

You can access DND, find my phone, raise to wake gesture, alarms, brightness and settings.



Swipe left or right to access records and monitors

You can access daily activity and sports records, heart rate monitor, blood oxygen monitor, temperature monitor, sleep monitor, music control, weather forecast and notifications from here.



Swipe up to view live cricket scores.

Enable this feature from the app to use.



SYNCING YOUR SMARTWATCH TO THE APP

Data Synchronization

• Open the app on your phone.

• Make sure your Cosmos is connected to the app.

• Synchronization will start automatically once you enter the app interface.

Note: Synchronize data at least once every day to avoid data loss in the watch.

Energy Score

Track your energy level throughout the day with the Energy Meter score on the app. Click on the Energy Meter value on the App Dashboard to see detailed insights as well as historical data of energy spent.

The energy meter takes into account various parameters like your age, BMI, sleep data, activities performed etc. and gives you a real time update of your energy level on a scale of 100.

NAVIGATING THROUGH THE FUNCTIONS

Changing the dial interface

Using the app

Select cloud watch faces on the app and push your preferred watch face to your smartwatch.

Go to the boAt crest app -> Settings-> Cosmos features-> Watch faces.

Note: Make sure your watch and phone are connected via Bluetooth. Do not exit the downloading interface until it displays 100% downloaded. It may take up to 60 secs to sync the watch face with the app.

Using the Cosmos

Long press the home screen to select the watch face.

Go to settings of the watch -> Display -> Watch face -> Select the watch face of your choice.



App features

Home screen

You can access steps, HR, spo2, sleep,energy meter data here.

Swipe left to access Fitness plans

Make your custom fitness plans based on your BMI.

Swipe left to access 700 active modes

Click on the >> icon to select the activity from the list of categories

For instance, click on bicycling, click the next button. Once you get in you can select any activity of your choice from this category, click the next button.

Maintenance:

Regularly clean your wrist and the strap of the smartwatch, especially after sweating during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product.

Do not wash the strap with a household cleanser. Please use soap less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.

For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.

PRODUCT PARAMETERS:

Model	boAt Cosmos
Screen Type	1.78" AMOLED Display
Battery Capacity	230 mAh
Net weight	45g
Bluetooth version	Bluetooth 5.0
Working temperature	-20 ~ 60 degree
Charging time	about 30 mins
Working time	about 7 days
Maximum transmit power	8dBm
Frequency band	2402 - 2480 MHz

FAQ

Search for the app to connect keeps failing

1. Keep the boAt Crest app updated to the latest version

2. Close all the programs on the watch -> Stop and restart Bluetooth and GPS -> Connect again

3. Check and enable notification functions of your phone and keep the phone and watch in close contact.

Note: Make sure your phone system meets Android 7.0 and above and iOS 13.0 and above.

My Cosmos is receiving no alerts, texts, or phone calls

Make sure smart reminders on the app are on and synced to the Cosmos.

Also make sure your notification center of the phone is displaying messages. Only then will your smartwatch also display those notifications.

My Bluetooth keeps getting disconnected

Make sure there is not more than 7m distance between Bluetooth on the phone and the watch.

There is no obstacle in between the watch and the phone.

Which functions of the Cosmos need Bluetooth to work?

Call & Text Notifications, Find My Phone, music control, cloud and custom watch faces need Bluetooth connectivity to work.

The time displayed on my phone and on the Cosmos are inconsistent

Make sure your watch Cosmos is connected to your phone through the app and not your phone's Bluetooth feature itself.

Will it be okay to take a bath wearing the COSMOS?

The IP68 water resistance will only work under the following conditions:

(1) Maximum depth of water: 1.5m (2) Maximum time for exposure to water: 10 minutes

The watch isn't suitable for hot baths, hot springs, saunas, snorkeling, diving, water skiing and other wading or deep-water activities with high-speed water flow.

Why is my blood oxygen level measurement not accurate?

The measurements are for reference only because there is a different way to measure your blood oxygen levels on your watch and a different way when medical equipment is used.

How do I receive live cricket scores?

Go to app home page-> click on the cricket icon top right corner-> select the match for which you want to receive notifications -> Select the time interval.

Note: Notifications can be received for 1 match at a time.

What is the average rate of fast charging?

Watch will be fully charged in 30 minutes.

SAFETY & PRODUCT INFORMATION

Battery

• Do not disassemble, bore or damage the battery.

• Do not disassemble the built in batteries of non-replaceable battery devices.

• Do not use sharp objects to remove the battery.

Health Warning

• If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch.

• The optical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician before wearing this device.

• The device tracks your daily activities through sensors. This data is intended to tell you about your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort you contribute to recycle valuable raw materials and treatment of toxic substances.

