



# Ardopes 511v2 Twin Wireless Ear-buds

Get ready to immerse yourself in musical bliss with your very own pair of Ardopes 511v2. Please consider this manual as your guiding map towards the shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual; also, you may refer to the same at times when you face any sort of difficulty in future.

TRUE WIRELESS | BLUETOOTH V5.2  
ERGONOMIC NEVER DROP DESIGN  
STEREO CALLING FEATURE


Ardopes 511v2  
Twin Wireless Ear-buds

## In the box

- 1x Pair of Ear-Buds
- 1x Charging Case
- 1x Pair of Ear-Caps
- 1x User Manual
- 1x Charging Cable

## Product Overview

- MFB (Multi-Function Button) / Power Button
- Indicator Lights
- Charging Case Indicator
- Micro USB Charging Port



## Power On (First Time User)

**Step 1:** To automatically switch the earbuds on Smart Power On, simply take them out from the charging case.

**OR**

To manually switch the earbuds on Manual Power On, long press the Multifunction button (MFB) for 3 seconds on both left and right earbuds for switching on until the LED light begins to flash in blue.

**Step 2:** Both Earbuds will automatically pair with each other. The earbuds will automatically enter connection mode if you manually switch the earbuds on.

**Step 3:** Turn on the Bluetooth functionality on your smartphone/tablet/laptop.

**Step 4:** Search for "Ardopes 511v2" and pair accordingly. Enter "0000" as the pairing code.

**Congratulations! Your earbuds are now connected successfully to the Bluetooth.**

**NOTE:** Technology Ardopes 511v2 comes equipped with our advanced Hi-Fi Pure Technology. See details list of the various uses for which our earbuds are best suited on our website.

**Notes:**

- 1. Pairing mode lasts for 3 minutes. If pairing time is missed, the earbuds will automatically return to the factory reset mode.
- 2. Ardopes 511v2 earbuds are previously connected during, once connected by the back, automatically reconnect to the previously connected device.



## Single Earbud Usage

**Step 1:** Please note that both the earbuds can be used in mono mode. Use either of the two options: Smart Power On or Manual Power On for switching on the desired earbud.

**Step 2:** The selected earbud will automatically enter the connection mode indicated by alternating blue & red LED flashes.

**Step 3:** Turn on Bluetooth on your phone/media device and search for "Ardopes 511v2" to connect.

**Notes:**

- To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, hence enabling Stereo usage.
- You cannot skip tracks or return to the previous tracks in Mono mode.




## LED Indicators / Functionalities

2 Seconds	Long press the Multifunction button on either earbuds for 2 seconds to activate voice assistant (Google/ Siri) before incoming calls.
3 Seconds	Manual Power On: Long press the Multifunction button for 3 seconds on left or right earbud for switching them on manually. LED light begins to flash in blue level.
5 Seconds	Manual Power Off: Long press the Multifunction button on either earbuds for 5 seconds to manually turn off the earbuds. Also LED light flashes 4 times before turning off.
Triple Press	Factory Reset: Press both the earbuds back into the charging case in correct orientation to switch them off. Well for the LED red and light 10 times press the MFB on both Left and Right earbuds to perform the factory reset and the earbuds flashes with alternating red & blue LED.

## Charging The Case

**Step 1:** To charge the case, plug one end of the provided cable into the case and connect the other end to a computer or a wall adapter.

**Step 2:** The LED lights located on the charging case indicate the battery status of the case. Once fully charged all the four LEDs stay solid.



Battery Indicator (When Charging)	
0% - 25%	The first Blue LED flashes slowly
25% - 50%	The second Blue LED flashes slowly
50% - 75%	The third Blue LED flashes slowly
75% - 100%	The fourth Blue LED flashes slowly

## Charging The Earbuds

**Step 1:** Please insert the earbuds back inside the charging case in correct orientation.

**Step 2:** A red LED will indicate that the earbuds are being charged. Once fully charged the LED stays off.

**Step 3:** Once the earbuds are fully charged, the charging case automatically switches off to save power.

**Note:**

- Before using the ear buds for the first time, it is recommended to fully charge the ear buds. Also, please keep the lid of the charging case closed while charging and use a 5V/2A adaptor.
- When the earbuds are in low power, flashing red LED indicates the same.



## Basic Functions

- Voice Assistant:** Long press the Multifunction Button on either earbud for 2 seconds to activate the voice assistant.
- Answer/Hang Up Call:** Single press the Multifunction Button on either earbud to answer an incoming call and once again to hang up an ongoing call.
- Reject Call:** Long press the Multifunction Button for 2 seconds to reject incoming calls.
- Play/Pause Music:** Single press the Multifunction Button on either earbud once to play or pause a song.
- Next Track:** When playing music, double press the MFB on right earbud to skip to the next song.
- Previous Track:** When playing music, double press the MFB on left earbud to return to the previous song.

**Note:** Volume cannot be controlled via earbuds and can only be adjusted via phone/media device.

## Voice Assistant

**Step 1:** Long press the Multifunction Button on either earbud for 2 seconds to activate the voice assistant.

**Step 2:** The respective voice assistant screen pops up and you may place your commands at ease.

**Tip:** You may play the following commands:

- What is the weather?
- Play a song.
- Where are The Pyramids located?



## Smart Power Off

**Step 1:** After usage, remove both the earbuds from your ears.

**Step 2:** Place the earbuds back into the charging case in correct orientation.

**Step 3:** The earbuds will automatically switch off (and enter into charging mode indicated by red LED).



## Manual Power Off

**Step 1:** Long press the MFB on either earbud for 5 seconds until the red indicator light blinks 4 times before earbuds getting turned off. In order to manually switch off the earbuds. Please note that this powers off both the earbuds.

**Step 2:** Please keep the earbuds back into the charging case to charge the earbuds.

## Factory Reset

Perform the Factory Reset in case you face any difficulty while operating your 511v2.

**Step 1:** Place both the earbuds back into the charging case in correct orientation to switch them off.

**Step 2:** Long press the MFB on both Left and Right earbuds to perform the factory reset until the indicator flashes with alternating red & blue LED.

**Step 3:** Shut the lid of the charging case and then re-open it again.


**Step 4:** Once you take the earbuds out from the charging case, they automatically restart.

**Congratulations! Your Ardopes 511v2 has been Reset.**




## Common Problems with Solutions

**If only one earbud is functioning:**



If only one earbud is functioning: Simply insert the earbuds back into the case and take them out or perform the Factory Reset.

**If earbuds are not in scan mode (No alternating blue and red LED flashes on the earbuds):**



If Earbuds not in Scan mode: No alternating blue and red LED flashes on the earbuds. Simply put back both the earbuds in case and take out again or perform "Factory Reset".

## Specifications

Model Type	TWS
HD Sound	Yes
Bluetooth Version	V5.2
Water Resistance	IPX4
Music Playback	Up to 1 Hour
Transmittance Range	10m
IMC	<math>40\text{ dB}</math>
Transparency	Yes
Driver Size	6mm
Bluetooth Profile	HFP, HSP, A2DP, AVRCP
Frequency	2.4GHz
Battery Earbuds	40mAh x2
Battery Charging Case	300mAh
Charging Time	2 Hours
Control Method	5-Buttons

## Troubleshooting

Potential Problem	Solution
If one earbud is not working	Perform the Factory Reset
If earbuds are not in connection	Perform the Factory Reset
If earbuds are not in scan mode	Perform the Factory Reset
If earbuds are not charging properly	Charge the earbuds using the provided charging case
If there are any other exceptions or usage	Charge the earbuds using the provided charging case and try using them on any other earbuds that support Bluetooth

## Warning

- Please follow the instructions to operate.
- Please charge the ear buds according to the charging norms mentioned on the packaging & manual.
- Please don't use the ear buds in extreme temperatures.
- Please don't use the product near water.
- Please keep the product away from heat sources, as the heat may damage it.
- Don't jam the ports such as charge port, LED port, etc.
- It is recommended to allow the product below the maximum volume in order to protect hearing and extend the ear buds' service life.

Adjustable: The earbuds start at a 100% volume and it may need to be reduced when the earbuds are switched on at first. This can be done by using the volume control on the phone/media device.

## Charging Norms & Precautionary Guidelines:

1) Charger/Bulk Adapter	5V/2A
1) Cable Wire	Standard Cable (3 Strands with 3mm diameter strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.



TRUE WIRELESS | BLUETOOTH V5.0  
ERGONOMIC NEVER DROP DESIGN  
STEREO CALLING FEATURE

Ardopes 511v2  
Twin Wireless Ear-buds