



Airdopes 641

Get ready to immerse yourself in musical bliss with your very own pair of boAt Airdopes 641. Please consider this manual as your guiding map towards the unparalleled shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual; also, you may refer to the same at times when you face any sort of difficulty in future.

Packaging Contents

- 1x Pair of TWS Earbuds
- 1x User Manual
- 1x Charging Case
- 1x Warranty Card
- 2x Pairs of Additional Earmuffs
- 1x Catalogue
- 1x Type-C Charging Cable

Product Overview:



Power On (First Time User)

Step 1: To switch the earbuds on (Smart Power On) simply open the lid of the charging case (when earbuds are inside). Our IPW™ (Inta Wake N Pair) Technology enables the earbuds to power on automatically, get connected and enter into the connection mode.

OR

Long touch the CTC on both earbuds for 3 seconds to manually power on the earbuds

Step 2: Both the earbuds will automatically pair with each other. The earbuds will enter into the Connection Mode, indicated by green LED flashes.


Connection Mode

Step 3: Turn on the Bluetooth functionality on your phone/media device and scan.

Step 4: Search for 'Airdopes 641' and pair accordingly.

Congratulations! Your earbuds are now connected successfully via Bluetooth.

Note: Pairing mode lasts for 5 minutes. If the pairing time is missed then you will need to reconnect the earbuds and follow the above mentioned procedure. Airdopes 641 remembers previously connected devices; once switched on, the earbuds automatically reconnect to the previously connected devices.



Single Earbud Usage

Step 1: Please note that both the earbuds can be used in mono mode. Use Smart / Manual Power On for switching on the desired earbud.


Step 2: The selected earbud will automatically enter the connection mode indicated by green LED flashes.

Step 3: Turn on Bluetooth on your phone/media device and search for 'Airdopes 641' to connect.

Notes:


• To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, hence enabling Stereo usage.

• You cannot skip tracks or return to the previous tracks in Mono mode.



Charging the Earbuds

- 2 Seconds: Long touch either CTC for 2 sec to activate voice assistant
- 3 Seconds: Long touch both CTCs for 3 seconds to manually power on
- 5 Seconds: Long touch either CTC for 5 seconds to manually power off
- 10 Seconds: Long press the CTC on both earbuds inside the case for up to 10 seconds for reset



Charging the Case


Step 1: Please insert the earbuds back inside the charging case in correct orientation.

Step 2: A solid green LED indicates that the earbuds are being charged. Once fully charged the LED turns off.

Step 3: Once the earbuds are fully charged, the charging case automatically switches off to save power.

Notes:

• Before using the ear-buds for the first time, it is recommended to fully charge the ear-buds. Also, please keep the lid of the charging case closed while charging.



Basic Functions

• **Voice Assistant:** Long touch the CTC on either earbud for 2 seconds to activate the voice assistant.

• **Answer/Hang Up Call:** Single tap the CTC on either earbud to answer an incoming call and once again to hang up an ongoing call.

• **Reject Call:** Long touch the CTC for up to 1.5 seconds to reject incoming calls.

• **Play/Pause Music:** Single tap on either earbud's CTC to play or pause music.

• **Next Track:** When playing music, double tap the right CTC to skip to the next song.

• **Previous Track:** When playing music, double tap the left CTC to return to the previous song.

• **Beast Mode:** Your Airdopes 641 is the right companion for a better gaming experience. Bionic Engine And Sonic Technology offers true real time audio embedded sequence for gaming and entertainment. Tap the left earbud's CTC four times to enter the BEAST mode for a great gaming experience, and once again tap the left earbud's CTC four times to turn it off.

Note: It is advisable not to use the Carry cum Charge case as a power bank unless there's some sort of emergency. Volume can only be controlled via the media device.

Voice Assistant

Step 1: Long touch the CTC on either earbud for 2 seconds to activate the smart voice assistant.

Step 2: The respective voice assistant screen pops up and you may place your commands at ease.

Tips: You may try the following commands,

- What is the weather?
- Play a song
- Set a reminder



Smart Power Off

Step 1: After usage, remove both the earbuds from your cars.

Step 2: Place the earbuds back into the charging case in correct orientation.

Step 3: The earbuds will automatically switch off (and enter into charging mode).

Manual Power Off

Step 1: Long touch the CTC on either earbud for 5 seconds.

Step 2: Once the earbuds get turned off, place them back inside the case and close the lid.

Factory Reset

Perform the Factory Reset in case you face any difficulty while operating your Airdopes 641.

Note: Before performing reset, clear 'Airdopes 641' from pairing device history by forgetting device.

Step 1: Place both the earbuds back inside the charging case in correct orientation.

Step 2: Long press the CTC on both earbuds inside the case for up to 10 seconds to do Factory reset, which is indicated by the flashing of green LED three times.

Step 3: Shut the lid of the charging case and then re-open it again.

Step 4: Once you take the earbuds out from the charging case, they automatically restart.

Step 5: Congratulations! Your Airdopes 641 has been Reset.

Troubleshooting

Potential Problem	Solution
If one earbud is not working	Perform the Factory Reset
If earbuds are not in connection/scan mode	Perform the Factory Reset
If earbuds disconnect during phone call	Charge the earbuds or perform the Factory Reset
If there are other exceptions in usage	Place the earbuds back into the charging case and try using them again or perform the Factory Reset
If the Touch Controls don't seem to respond	After long usage, residual static and perspiration can affect the touch control area; please use a clean cloth to wipe those areas softly.

Charging norms & Precautionary Guidelines:	1) Charger/Brick/Adapter	• 19.2A
Any other accessories can be paired up with the product as long as the specifications are as per above norms.	2) Cable/Wire	• Standard Cable (3.5 Strands, 6ft/1.8m) (Diameter) 18 AWG

Specifications

Bluetooth Version	V5.0
Water Resistance	IPX5
IWP Technology	Yes
Music Playtime	Up to 6H per charge; Up to 24H additional with Case
BEAST Mode (Gaming Mode)	Yes
Standby Time	420H
Transmission Range	10m
Driver Size	6mm*4
Bluetooth Profiles	HFP / HSP / A2DP / AVRCP
Frequency	20KHz - 20KHz
Battery	500mAh (Case) 40mAh*2 (Earbuds)
Charging Time	About 1.5 hours Earbuds; 1.5-2 hours Case
Charging Interface	Type C
RGB Lights	Yes

Warning:

- Please follow the instructions to operate.
- Please don't use the ear-buds in extreme temperatures.
- Please don't use the product near water.
- Please keep the product away from heat sources, as the heat may damage it.
- Don't jam the ports such as charger port, LED port, etc.
- It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the ear-buds' service life.

Advisable: The earbuds start at a 100% volume and it may need to be reduced when the earbuds are switched on at first. This can be done by using the phone / media device.