

Thank you for choosing the boAt Rockerz 238. This manual is meant to guide you through to the shores of Nirvana without much difficulty. Please think of this manual as your map. Knowledge of Bluetooth and device connection is essential for steering this boAt. Therefore, we strongly advise that this manual is thoroughly read before use, and referred to in times of difficulty.

Package contents

- 1 x boAt Rockerz 238
- 1 x Micro USB charging cable • 2 x Additional Earmuffs (S & L)
- 1 x Manual
- 1 x Warranty Card

Product Diagram:







Power On: Press and hold the Multifunction button (MFB) for 3 seconds. The blue LED light blinks to indicate the

Power Off: Press and hold the MFB button for 3 second. The red LED light blinks to indicate the same.

- 1. Turn on Bluetooth in your phone and long press the MFB on Rockerz 238 for 6 seconds until red and blue LEDs blink to indicate the connection mode
- 2. Then, click on 'Rockerz 238' from the list available devices after search
- If asked for a passkey, confirm the passkey '0000' on phone
 Once confirmed, the headset and phone gets connected via Bluetooth indicated by flashing blue LED once every few seconds



Note: If there's a connection history between the phone and the headset, then they automatically get reconnected in a working range.

- Charging


 Connect the charger to the charging port on the headset
- While charging the indicator light will turn into red
 When the headset is fully charged, the indicator LED turns into blue
- This wireless headset supports fast Charging technology
 Use only authorized/company chargers for the headset, as unauthorized ones may damage the same and invalidate the warranty on the headset as well

Basic Functions

Volume Up Volume Down Next Track Previous Track Answer Incoming Calls Hang Up Ongoing Calls Reject Calls Charging

Redial Voice Assistant

Short press the MFB once to play Short press the MFB once to pause Press'+'button in steps to increase volume Press '-' button in steps to decrease volume Press and hold '+' button for skipping to next track Press and hold '-' button for returning to the previous track Single press the MFB to attend an incoming call Single press the MFB to end an ongoing call Press and hold the MFB for 2 seconds to reject incoming calls Connect the charger to the charging port, the indicator will turn red while charging. Once fully charged, the LED turns into blue Double press the MFB to redial the last called number Long press the MFB for 1.5 seconds to activate voice assistant



VIBRATION ALERT:

This headset supports vibration alert. Whenever you're receiving a call from someone, this headset will vibrate to notify you.

This headset supports fast charging. 20 minutes of charge will give you upto 4 hours of playback time. 1 hours of charge will fully charge your headset.

Specifications

Model	Rockerz 238
Headphone Type	Bluetooth Headset
Driver Size	10mm
THD	1%
Frequency Range	20Hz~20KHz
SNR	≥75dB
Water Resistance	IPX5
Bluetooth Version	5.0
Bluetooth Profile	HFP, HSP, A2DP, AVRCP
Bluetooth Range	10m
Battery Capacity	150mAh
Playing Time	Up to 8 hours
Fast Charging	Yes
Charging Time	1.5 hours
Charging Voltage	5V
Product Weight	31g

Safety Cautions:

 Please don't dismantle the product in any way or remove the product's battery by yourself, as this can lead to a fire or electrical breakdown. Any maintenance or servicing of the earphones should be done only through a qualified service provider/manufacturer.

• Please clean the earphones with the utmost of care with only a damp soft cloth, if cleaning is required. Please do not use any oily volatile liquid. In addition, ensure that the earphones are kept away from extremely hot or cold

 Any damage to the earphones that is NOT a manufacturing issue will make the products warranty null and void. • Do not use earphones when it is unsafe to be wearing them, such as while operating a vehicle, crossing a street, or during any activity where full awareness of your surroundings is required.

To avoid damage to your hearing, make sure that the volume on your music player is at an appropriate level
when you are Plugging into Nirvana. Exposure to any noise levels at or above 85 dB can gradually lead to a loss of

Charging norms & Precautionary Guidelines: -

1) Charger/Brick/Adapter: 5V 2A

2) Cable/Wire: Standard Cable (35 strands @0.10mm diameter/ strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.

