

## ROCKERZ 333ANC





USER MANUAL

## ROCKERZ 333ANC

Thank you for choosing boAt Rockerz 333ANC. This manual is meant to guide you through the functionality of the wireless earphone neckband. Knowledge of Bluetooth and device connection is essential for the usage of the headset. Therefore, we strongly advise that this manual be thoroughly read before use, and referred to in times of difficulty, so that you can always be easily guided towards the shores of musical bliss.

### PACKAGE CONTAINS:

- 1 x boAt Rockerz 333ANC
- 1 x USB Type C Charging Cable
- 2 x Additional Earmuffs
- 1 x Catalogue
- 1 x User Manual
- 1 x Warranty Card



### TO PAIR WITH BLUETOOTH

- (1) When switched off, press and hold the MFB (\*Multifunction Button) for 3 seconds to switch on the wireless earphones and put them into pairing mode. The earphones automatically enter pairing mode with a voice prompt, the blue and red LEDs flash to indicate the same.
  - (2) Open Bluetooth functionality on your media device and search for "Rockerz 333ANC" from the list of available devices.
  - (3) Choose "Rockerz 333ANC" from the list and if asked for a passcode, enter the pairing code "0000" to establish Bluetooth connectivity.
  - (4) Once successfully connected, the blue LED flashes to indicate the same.
- Note: The wireless neckband automatically turns off if there is no pairing established in 5 minutes.

### FUNCTIONS

- (1) **Power On:** When switched off, press and hold the MFB for 2 seconds to power on the neckband. Red LED flashes once to indicate the same.
- (2) **Power Off:** In powered on state, press and hold the MFB for 5 seconds. Red LED flashes before the device gets turned off.
- (3) **Play/Pause:** Short press the MFB to play/pause music at your convenience.
- (4) **Volume Up:** Short press the Volume Up "+" button in steps to increase the volume. A voice prompt indicates maximum volume.
- (5) **Volume Down:** Short press the Volume Down "-" button in steps to decrease the volume.

Front

(6) **Answer/End call:** Short press the MFB once when answering or ending a call to complete the action.

(7) **Reject call:** Double press the MFB during an incoming call to reject the call.

(8) **Previous Track:** To go back to the previous track or start the track from beginning, press and hold the Volume Up "+" button for 1 sec.

(9) **Next Track:** To skip to the next track, press and hold the Volume Down "-" button for 1 second.

(10) **Reset Device (Clear Paired List):** Press and hold the Volume Up and Volume Down buttons simultaneously for 5 seconds to clear the list of paired devices. The blue and red LEDs flash rapidly to indicate the same.

(11) **Dual Pairing:** To connect Rockerz 333ANC to two devices simultaneously, firstly connect the earphones to one of the devices. Then, switch off the device's Bluetooth. Thereafter, connect the earphone to the second device, and again switch on the first device's Bluetooth. The earphone gets connected to both devices. If not, connect the first device manually once again to activate dual pairing.

(12) **ENx™ Tech:** Our ENx™ tech algorithm cancels out the background noise so that you can be heard crystal clear via voice calls. One need not activate ENx™ as the mic is equipped with the same and activated by default.

Deliver your voice without interruptions anywhere - traffic, railway stations, airports, work space, literally anywhere!

(13) **Voice Assistant:** Triple press the MFB to wake up default smart voice assistant.

### CRYSTAL BIONIC SOUND POWERED BY DIRAC OPTEO™

Dirac Opteo™ maximizes the sound performance yielding incredible delivery with lower lows, higher highs and a mid-range so exquisite that you can feel it. Rockerz 333ANC offers Crystal Bionic Sound powered by Dirac Opteo™ for a crystal-clear sound quality and device independent built-in HD audio.

To switch on Crystal Bionic Sound, simply double press the MFB. To switch off Crystal Bionic Sound and enter into Battery Saver Mode, double press the MFB once again.

### ANC MODE / AMBIENT MODE /ANC OFF

• Single press the ANC button to active ANC mode that cancels out the unwanted background noises so that you can stay immersed in your music without interruptions.

• Single press the ANC button once again to switch to Ambient mode that lets you stay aware of your audible surroundings, even during playback.

• Single press the ANC button again in order to switch to Normal mode (ANC off, Ambient Mode off).

Note: By default, before using the neckband for the very first time it stays in ANC OFF mode.

### POWER (BATTERY) SAVER MODE

• To activate battery saver mode (turning off Crystal Bionic Sound + ANC), simply double press the MFB. It gets indicated by a sound prompt.

• To deactivate battery saver mode (turning on Crystal Bionic Sound), double press the MFB once again. It gets indicated by a sound prompt.

1. Battery saver mode gets activated automatically once the remaining battery goes below 20%.
2. By default, whenever you turn on the earphones, it starts in Battery Saver Mode.

### TO CHARGE

Use the provided USB Type C charging cable to charge the earphones through either laptop / adaptor/ powerbank.

(1) **Low Battery:** When the remaining battery is below 20%, there is a 'Battery Low' prompt every few minutes and red LED quickly flashes every few seconds to indicate the same.

(2) **Charging:** Solid red LED indicates that the earphone is being charged (please note that the earphone cannot / should not be turned on while charging).

(3) **Fully charged:** Solid white LED indicates the same.

### SAFETY PRECAUTIONS

• Please don't dismantle the product in any way or remove the product's battery by yourself, as this can lead to a fire or electrical breakdown. Any maintenance or servicing of the earphones should be done only through a qualified service provider/manufacturer.

• Please clean the earphones with the utmost of care with only a damp soft cloth, if cleaning is required. Please do not use any oily, volatile liquid. In addition, ensure that the earphones are kept away from extremely hot or cold substances.

• Any damage to the earphones that is NOT a manufacturing issue will make the products warranty null and void.

• Do not use earphones when it is unsafe to be wearing them, such as while operating a vehicle, crossing a street, or during any activity where full awareness of your surroundings is required.

• To avoid damage to your hearing, make sure that the volume on your music player is at an appropriate level when you are putting on the earphone. Exposure to any noise levels at or above 85 dB can gradually lead to a loss of hearing.

### SPECIFICATIONS

Bluetooth Version:	V5.2
ANC:	Yes (Up to 25dB)
ENx™ Tech:	Yes
Operating Range:	10m
Frequency:	20Hz-20kHz
Driver Size:	13mm <sup>2</sup> Drivers
Battery:	220mAh
Talk time:	Up to 24 hours
Music time:	Up to 24 Hours in Power Saver mode w/o ANC, Up to 20 Hours in Crystal Bionic Sound mode w/o ANC, Up to 15 Hours in Power Saver mode with ANC, Up to 13 Hours in Crystal Bionic Sound mode with ANC (At 60% volume)
Bluetooth Profile:	HFP/HSP/A2DP/AVRCP
Charging Time :	About 1.5 hours
Charging Port :	USB Type C
Ambient Mode:	Yes
ASAP Charge:	Yes
10 Min ASAP Charge:	Playtime= 3.5H ANC ON & Crystal Bionic Sound ON; 4.5H ANC ON & Crystal Bionic Sound OFF; 5.5H ANC OFF & Crystal Bionic Sound ON; 6H ANC OFF & Crystal Bionic Sound OFF
Water Resistance:	IPX4

### Charging norms & Precautionary Guidelines: -

1) Charger/Brick/Adapter	5V 2A
2) Cable/Wire :	Standard Cable (35 strands @0.10mm diameter/ strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.



Back