

boat

STONE 105

Thank you for purchasing the boAt Stone 105. You are now just a step away from the realm of pure audio bliss. Please follow this user manual carefully in case of any doubts and difficulties that arise

Please note that play time will vary depending on the selected volume level. You can stay plugged into the sound with Bluetooth wireless technology, TF and FM mode compatibility. This portable wireless speaker has been designed for smooth interface that requires the minimal of efforts.

- •1N Portable Bluetooth Speaker •1N Micro USB Charging Cable
- 1N User Manual
- •1N Catalogue
- 1N Warranty Card

POWER ON/OFF

Long press the MFB (Multi-Function Button) for 3 seconds to switch the speaker on. Similarly, long press the MFB again for 3 seconds to switch the speaker off.





- 4. Micro USB Charging port 5. TF card slot 3. Volume down/Previous song button 6. Mic position

BLUETOOTH CONNECTIVITY

BASIC FUNCTIONS

Reject the call Voice Assistant

Next Track

- 1. Turn the speaker on and the LED blinks in blue colour
 2. Activate the phone's Bluetooth functionality and search for "Stone 105". As soon as the speaker gets selected by you and paired, there comes a sound prompt indicating pairing and the blue LED turns steady

Long press MFB "O" for 8 seconds

Play time varies according to the level of volume.
 If the speaker doesn't turn off or doesn't respond properly, you could use the Reset functionality.

-The speaker gets automatically reconnected to the last paired device.

-The speaker gets automatically turned off if there's no pairing established in 10 minutes.

TWS CONNECTION:

- Double press the MFB on one of the speakers to establish TWS connectivity.
 A tone gets heard again along with the blue LED turning steady; it may take a few seconds before the two speakers get connected.

 4. Activate the phone's Bluetooth and search for "Stone 105" to establish pairing.

TF MODE

- Turn on the speaker
 Insert a Micro SD card in to the TF card slot and it will switch to TF card mode automatically

- Press "+" button and MFB simultaneously to switch to FM mode.

 Under FM mode, long press the "+" and "-" buttons to start scanning the radio.

. You may use the provided USB cable to work as an antenna for clarity in the FM mode.

end to an adaptor of DC 5V 2A.

- During the charging state, the charging LED indicator is solid red in colour.
 Once the battery gets fully charged, Charging LED turns off

Bluetooth Version	v5.0
Net weight	235g
Working range	10m
Driver size	2"
Charging Interface	Micro USB
Water Resistance	IPX4
Standby Time	120H
Frequency Response	180±20%HZ
Compatibility	Bluetooth, TF, FM
Output Power	5W
Charging time	Up to 2.5H
Playing time	Up to 11Hours at 80% volume (playtime varies according to the volume)
Battery	800mAh

Charging Norms & Guidelines: Charger/Adapter at 5V/2A and Standard Cable (35 strands @0.10mm diameter/strand)

1. Volume up/Next song button 2. MFB Button

- Please keep this product safe from coming in contact with any liquid.
 Don't use/store this product in extreme temperatures.
 Please keep the product away from anything that generates heat, such as radiators.
- songs on maximum volume.

 Don't try to dismantle / repair the product on your own.



