

Thank you for purchasing Stone Cuboid. You are now just a step away from the realm of Nirvana. Please follow this user manual carefully in case of any doubts and difficulties that arise. Please note that play time varies depending on the selected volume level. You can stay plugged into the sound with Bluetooth wireless technology, TF Card, FM & aux wire compatibility. This portable speaker has been designed for smooth interface that requires the minimal of efforts.

Package Contents

- 1N Rhijetooth Speaker
- 1N Micro USB Charging Cable • 1N Audio Cable
- 1N User Manual
- 1N Warranty Card • 1N Catalogue



Product Overview

- 1 MER (Multifunction Button)
- 2. Volume Button
- 3. LED Indicator
- 4. Volume + Buttor 5. Mode Button
- 6. Silicone Openino

Power ON/OFF

You may long press the MFB to switch the speaker ON/OFF.

Functions:

- Answer Incoming Calls: Short press the MFB once • End Calls: Short press the MFB once to end calls
- Reject Incoming Calls: Double tap the MFR
- · Switch Modes (Bluetooth / FM): Single tap the Mode button to select modes: Bluetooth or FM
- Volume Increase: Short press the "+" button in steps for increasing. Volume Decrease: Short press the "-" button in steps for decreasing.
- Play/Pause: Short press the MFB to play or pause the tracks
- Previous Track: Long press the "-" button for returning to the previous
- Next Track: Long press the "+" button for skipping to the next track Next Station (FM): Long press the "-" button for switching to next.
- Previous Station (FM): Long press the "+" button for switching to
- Voice Assistant: Double press the mode button to wake up your
- smart voice assistant (in Bluetooth Mode)
- Disconnect Bluetooth: Single press the '-' and '+' buttons together to disconnect Bluetooth device

 The speaker can automatically reconnect to the last paired device · If you are having connection troubles, then remove Stone Cuboid from the

Bluetooth Connectivity

list of paired devices on your phone, keep the phone closer to the speaker and

prompt

. Turn the speaker on. Its LED indicator flashes rapidly in white until the pairing is done

Activate the phone's Bluetooth function and

speaker gets selected and paired by you, the

search for "Stone Cuboid". As soon as the

connection gets indicated by a sound

- You can switch to AUX mode by using the AUX cable to connect the phone and the speaker
- · In the AUX mode, you can control the audio playback via the media device/phone



FM Mode

- Please insert the micro USB cable into the speaker to utilize it as an antenna, turn on the speaker and by tapping the Mode button you
- · Single tap the MFB to activate/stop auto search for channels
- · Long press the "+"/"-" to select the channel



Charging

- · Stone Cuboid beeps once every 5 minutes when the battery is low.
- After three such indications, the speaker automatically turns off Utilize the provided charging cable to charge the speaker The LED indicator turns into steady red while charging: the same
- goes off as soon as the speaker gets fully charged

Please avoid using the speaker while it is in charge as it may decrease the battery's performance

Specifications

Speaker Type	Portable Wireless Mono Speaker
Bluetooth Version	V5.0
Working Range	10m
Speaker Size	1.75*
Water Resistance	IPX5
Compatibility	Bluetooth V5.0 / AUX / TF Card / FN
SNR	80dB
Frequency	70Hz-20kHz
Input Voltage	5V/2A
Output Power	5W
Play Time	Up to 5.5H
Talk Time	Up to 4H
Charging Time	1-1.5 hours
Battery	1200mAh
TF Compatibility	Yes
AUX Compatibility	Yes
EAA	Vor

Warning

4

- Please charge the speaker according to the charging norms mentioned
- on packaging to protect the battery
- · Do not disassemble the product
- · Do not submerge the product inside water Please keep this product safe from coming in contact with any liquid.
- Don't use/store this product in extreme temperatures
- · Please keep the product away from anything that generates heat. such as radiators, stoves, etc.
- · In order to have hearing protection and an extended speaker life,
- avoid listening to songs on maximum volume
- . Don't try to dismantle/repair the product on your own.





TF Card Mode

 You can switch to TF Card mode by inserting the TF card into the provided slot