

# STORM CALL 3 Thank you for choosing the boAt Storm Call 3 as your fitness transformation companion.

Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as well.




## CHARGING THE WATCH The smartwatch must be charged before initial use. It takes up to 2 hours to be fully charged

USB magnetic charging cable x1


Package Contains:

Warranty Card x1

Connect and charge the watch with the image below as a reference, using a 5V/2A adapter.



To restart or turn the watch on/off, long-press the side button for 3-5 seconds. You can wake up the screen by lifting your wrist.



# CONNECTING TO THE APP

1. Download the boAt Crest app on your phone.

Available on both App Store (iOS 12.0 and above) and Google Play Store (Android 7.0 and above)

# Scan [QR CODE] (Also available on the watch)

2. Connect the device with the boAt Crest app: ensure that the phone's Bluetooth as well as the GPS functionalities are

- 3. Select Storm Call 3 on the home screen of the app and click pair to connect.
- 4. Once connected, you will get an alert to connect with STORMCALL3\_XXXX, click pair if need to receive or make calls from the watch 5. To use all features of your Storm Call 3 seamlessly, tap on 'yes' to the 'connection' and
- 'grant access' system prompt.
- 6. Disable battery optimization



Note: To ensure connectivity throughout your journey, make sure the app is allowed to always run in the background of your phone.

# SYNCING YOUR SMARTWATCH TO THE APP

### Open the app on your phone

Make sure your Storm Call 3 is connected to the app.

- Synchronization will start automatically once you enter the app interface. Synchronize data at least once a day to avoid data loss in the watch.

## NAVIGATING THROUGH THE FUNCTIONS SHORT PRESS THE SIDE BUTTON FOR MAIN MENU

You can use the dialer to dial any number

Add up to 20 contacts from boAt Crest app. You can select any contact to directly dial from the watch.

## Call History

### Choose from multiple sports modes like Walking, treadmill,

Running, Badminton, Football, Basketball, Tennis, Yoga, Dancing, Cycling, Indoor Cycling, etc. The watch has 700+ activity modes. You can also add or replace the activities according to your preferences through boAt Crest app. Tap on any sport mode to start the activity, click the go button,

and the watch will start recording the duration of the activity. Swipe right to pause or stop the activity. The activity will not be recorded if it is less than 3 mins.

Sync your smartwatch to the app to get a detailed record of the



### Heart Rate Monitor Wear the watch on your wrist, then click on the icon to start

measurements. You can also view the data on the app.

Note: Measurements are for reference only and not for medical



### Wear the watch on your wrist, then click on the icon to start

measurements. You can also view the data on the app.

Once the asleep criteria are met, your smartwatch will start recording from 8

Once you lie down and watch detects no movement for 30 minutes, it will

For accurate sleep data recording, the asleep criteria have to be met which

start recording, and will stop recording if it detects excessive movement.

You can check the data on the app only after the awake criteria is met.

includes limited movement, wrist positions and angles, and more.

The awake criteria will be met only after it records some noticeable

Click on the breath exercises icon to regulate your breathing by doing breathing exercises. You can set the time and level of exercise.

Tap on the icon to review the sleep data of the previous night.

pm at night to 10 am in the morning the next day.

You can also track sleep scores on the boAt Crest app.

Note: Measurements are for reference only and not for medical

### Stopwatch Click on this to start the stopwatch on your watch.

Notification

You can check all the notifications from here



. The device tracks your daily activities through sensors. This data is intended to tell you about

The device accessories, heart rate sensor, oxygen level monitor, and other relevant data is

your daily activities such as steps, sleep, distance, heart rate and calories, but may not be

designed for fitness and not for medical purposes. They are not applicable to the diagnosis.

pressure data is for reference only. We're not responsible for any deviation in data.

monitoring, treatment or prevention of any diseases or symptoms. The heart rate and blood

. Avoid wearing the watch too tightly. Make sure you keep your skin dry - the area that comes

· Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents

Tap on the remote camera icon on your smartwatch to click a photo from your phone.

## Note: Turn the camera on from your phone to use this feature.


## Tap on the remote music control icon on your watch to play

music from your phone.



### Tap on this icon to find your phone. Once enabled, your phone will start

ringing and vibrating. Tap again to stop it.





Note: Some apps with different protocols might not work.





## Tap on this icon to change your watch face.

Watch Faces



### Tap on this and adjust the screen sleep time

# Tap on this to choose the ringtone and put the watch on silent

# Tap on this to adjust vibration levels from strong, soft and



Tap on this to restart, reset or to power off the smartwatch

Tap on this to turn on the Do Not Disturb mode.





## Tap on this to enable the voice assistant feature and give the

command from the watch. Note: Make sure the watch is connected with the app



### Tap on this to access the built-in game.

You can select from 2048 and Hamster



### Tap on this to access the QR of different applications. You can

you want to include.

transfer the QR code of metro ticket/pass, bus pass, UPI, social apps, and more into the smartwatch by adding the QR code in the boAt crest app. To add the QR code follow these steps: Click on "QR Tray" option in the boAt Crest app.



· After this, you'll be able to find a collection of QR codes in the smartwatch under the QR Tray feature. Select the QR code you want to be scanned.

## Tap on this to start navigating your route. Follow the steps to use

 Then send navigation instructions to your boAt smartwatch by clicking on get directions.

### After clicking on it choose the navigate on watch option.

Search your desired destination on the boAt Crest app.

 Then follow step-by-step instructions on your smartwatch to reach Note: The navigation is not shown in maps instead it is shown by direction arrows. You can access the last alert from the watch navigation menu or by swiping left from the home screen.

· To avoid receiving notifications on our smartwatch during navigation enable DND mode.


### SWIPE DOWN FOR SHORTCUT MENU You can access DND, Alarm, Find My Phone, Brightness, Navigation and

SWIPE LEFT OR RIGHT TO ACCESS ALL DATA. You can access daily activity, SpO2, Heart rate, sleep, phone and

## SWIPE UP TO ACCESS THE LIVE SCORE

notifications.

You can check the cricket live scores from here.



### · Open the boAt Crest app on your device. · Navigate to the "Home Dashboard."

SIDE BUTTON FUNCTIONALITY

In the "Top Features," you will find the "SOS" feature. Click on it to access the SOS functionality. To initiate an SOS call, perform a long press on the side button of your smartwatch. Note: You can add an emergency contact through the boAt Crest app.

| Model               | boAt Storm Call 3 |
|---------------------|-------------------|
| Screen type         | 1.83" HD Display  |
| Battery capacity    | 230mAh            |
| Net weight          | 41.5g             |
| Bluetooth version   | Bluetooth 5.2     |
| Working temperature | -20°C- 60°C       |
| Charging time       | 60 mins           |
| Working time        | 5 days            |
| Water Resistance    | IP67              |
| Frequency band      | No                |

Regularly clean your wrist and the strap of the smartwatch, especially after sweating during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product. Do not wash the strap with a household cleanser. Please use soap less detergent, rinse

thoroughly and wipe with a piece of soft towel or napkin For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.

### Search for the app to connect keeps failing

movement

Breathe exercises

2. Close all the programs on the watch → Stop and restart Bluetooth and GPS → Connect again

3. Check and enable notification functions of your phone and keep the phone and watch in Note: Make sure your phone system meets Android 7.0 and above and iOS 12.0 and above

My Watch Storm Call 3 is receiving no alerts, texts, or phone calls Make sure smart reminders on the app are on and synced to the Storm Call 3.

Also make sure your notification center of the phone is displaying messages. Only then will your smartwatch also display those notifications Make sure app is running in the background and battery optimization feature on the phone is disabled.

### My Bluetooth keeps getting disconnected 1. Make sure there is not more than 7m distance between Bluetooth on the phone & the watch.

2. There is no obstacle in between the watch and the phone.

Which functions of the Storm Call 3 need Bluetooth to work? Call & Text Notifications, Find My Phone, music control, camera control, weather forecast, cloud and custom watch faces and need Bluetooth connectivity to work.

Will it be okay to take a bath wearing the Storm Call 3? The IP67 water resistance will only work under the following conditions:

(1) Maximum depth of water: 1.5m (2) Maximum time for exposure to water: 10 minutes The watch isn't suitable for hot baths, hot springs, saunas, snorkeling, diving, water skiing and other wading or deep-water activities with high-speed water flow.

### SAFETY & PRODUCT INFORMATION

Do not disassemble, bore or damage the battery.

 Do not disassemble the built in batteries of non-replaceable battery devices. Do not use sharp objects to remove the battery.

blinking light sources, please consult your physician before wearing this device.

 If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch. The optical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to

in contact with the watch. If symptoms such as redness or swelling appear on your skin, immediately stop using the watch and consult the doctor. Things to keep in mind Sync data everyday days to avoid data loss.

### & other corrosive liquid. The damage or defects caused by misuse or improper use are not covered by the warranty. . Sports modes support up to 6 hours of exercise at a time.

. Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch

 Keep your arm still while measuring data for accurate measurement. Disclaimer: This product is an electronic monitoring product and is not intended as a medical

reference. We reserve the right to modify or improve any of the functions described in this manual without any prior notice. At the same time, we hold the right to continuously update the product

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Old electrical appliances must not be disposed of together with the residual waste. but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort you contribute to recycle valuable raw materials and treatment of toxic substances.