

# **WAVE SIGMA** Thank you for choosing the boAt Wave Sigma as your

fitness transformation companion.

Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as well.




## hoAt Wave Sigma x1

Package Contains:

# CHARGING THE WATCH

The smartwatch must be charged before initial use. It takes up to 2 hours to be fully charged. Connect and charge the watch with the image below as a reference, using a 5V/2A adapter.



To restart or turn the watch on/off, long-press the side button for 3-5 seconds. You can wake up the screen by lifting your wrist.

## CONNECTING TO THE APP

1. Download the boAt Crest app on your phone.

Available on both App Store (iOS 12.0 and above) and Google Play Store (Android 7.0 and above)

## Scan [QR CODE] (Also available on the watch)

2. Connect the device with the boAt Crest app; ensure that the phone's Bluetooth as well as the GPS functionalities are

- 3. Select Wave Sigma on the home screen of the app and click pair to connect.
- 4. Once connected, you will get an alert to connect with WAVESIGMA\_XXXX, click pair if need to receive or make calls from the watch 5. To use all features of your Wave Sigma seamlessly, tap on 'yes' to the 'connection' and
- 'grant access' system prompt.
- 6. Disable battery optimization



Shows the device details

command from the watch.

Shows the device regulatory details

Note: To ensure connectivity throughout your journey, make sure the app is allowed to always run in the background of your phone.

# SYNCING YOUR SMARTWATCH TO THE APP

### Open the app on your phone.

- Make sure your Wave Sigma is connected to the app.
- Synchronization will start automatically once you enter the app interface. Synchronize data at least once a day to avoid data loss in the watch.

# NAVIGATING THROUGH THE FUNCTIONS

# SHORT PRESS THE SIDE BUTTON FOR MAIN MENU

with the Phone's Bluetooth.

Click on "pair" to connect with the phone's Bluetooth. Alternatively, you can go to the phone's Bluetooth settings and pair

"WAVESIGMA\_XXXX" to start the calling feature on your watch. Note: Enable call alerts from the setting to get calls on the watch

boAt Wave Sigma

2.01" HD Display

230mAh

40.3g

Bluetooth 5.2

-20°C- 60°C

4-6 days

2.4GHz

PRODUCT PARAMETERS:

### Choose from multiple sports modes like Walking, treadmill,

Running, Badminton, Football, Basketball, Tennis, Yoga, Dancing, Cycling, Indoor Cycling, etc. The watch has 700+ activity modes. You can also add or replace the activities according to your preferences through boAt Crest app.

Tap on any sport mode to start the activity, click the go button, and the watch will start recording the duration of the activity. Swipe right to pause or stop the activity. The activity will not be recorded if it is less than 3 mins.

## Activity Record

**Heart Rate Monitor** 

Sync your smartwatch to the app to get a detailed record of the



### Wear the watch on your wrist, then click on the icon to start

Search for the app to connect keeps failing

your smartwatch also display those notifications.

My Bluetooth keeps getting disconnected

3. Make sure the app is running in background

Keep the boAt Crest app updated to the latest version

My Watch Wave Sigma is receiving no alerts, texts, or phone calls

2. There is no obstacle in between the watch and the phone.

Which functions of the Wave Sigma need Bluetooth to work?

The IP67 water resistance will only work under the following conditions:

and other wading or deep-water activities with high-speed water flow.

Will it be okay to take a bath wearing the Wave Sigma?

Make sure smart reminders on the app are on and synced to the Wave Sigma.

2. Close all the programs on the watch → Stop and restart Bluetooth and GPS → Connect again

1. Make sure there is not more than 7m distance between Bluetooth on the phone & the watch.

Call & Text Notifications, Find My Phone, music control, camera control, weather forecast, cloud and custom watch faces and need Bluetooth connectivity to work.

(1) Maximum depth of water: 1.5m (2) Maximum time for exposure to water: 10 minutes

The watch isn't suitable for hot baths, hot springs, saunas, snorkeling, diving, water skiing

3. Check and enable notification functions of your phone and keep the phone and watch in

Note: Make sure your phone system meets Android 7.0 and above and iOS 12.0 and above.

measurements. You can also view the data on the app.

Note: Measurements are for reference only and not for medical



### Wear the watch on your wrist, then click on the icon to start

SpO<sub>2</sub> monitoring

Sleep Monitor

movement

Breathe exercises

measurements. You can also view the data on the app.

Tap on the icon to review the sleep data of the previous night.

pm at night to 10 am in the morning the next day.

You can also track sleep scores on the boAt Crest app.

Once the asleep criteria are met, your smartwatch will start recording from 8

Once you lie down and watch detects no movement for 30 minutes, it will

For accurate sleep data recording, the asleep criteria have to be met which

start recording, and will stop recording if it detects excessive movement.

You can check the data on the app only after the awake criteria is met.

includes limited movement, wrist positions and angles, and more.

The awake criteria will be met only after it records some noticeable

Click on the breath exercises icon to regulate your breathing by doing breathing exercises. You can set the time and level of exercise.

Note: Measurements are for reference only and not for medical

# Stopwatch

Notification

Tap on this to set an alarm on your watch.

You can check all the notifications from here



· Do not disassemble, bore or damage the battery.

. Do not disassemble the built in batteries of non-replaceable battery devices.

· Do not use sharp objects to remove the battery.

SAFETY & PRODUCT INFORMATION

## Health Warning

- · If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch.
- The optical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician before wearing this device.
- . The device tracks your daily activities through sensors. This data is intended to tell you about your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.
- . The device accessories, heart rate sensor, oxygen level monitor, and other relevant data is designed for fitness and not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. The heart rate and blood pressure data is for reference only. We're not responsible for any deviation in data.
- · Avoid wearing the watch too tightly. Make sure you keep your skin dry the area that comes in contact with the watch. If symptoms such as redness or swelling appear on your skin, immediately stop using the watch and consult the doctor.

## Things to keep in mind

Sync data everyday days to avoid data loss.

- Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents & other corrosive liquid. The damage or defects caused by misuse or improper use are not
- Sports modes support up to 6 hours of exercise at a time.
- · Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

appliances to these collecting points or to similar collection points. With this little personal effort you contribute to recycle valuable raw materials and treatment of



Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the



# covered by the warranty.

Keep your arm still while measuring data for accurate measurement.

Disclaimer: This product is an electronic monitoring product and is not intended as a medical reference. We reserve the right to modify or improve any of the functions described in this manual without any prior notice. At the same time, we hold the right to continuously update the product

from your phone.

Tap on the remote music control icon on your watch to control music from your phone. Note: Some apps with different protocols might not work.

Note: Turn the camera on from your app to use this feature.

Tap on the remote camera icon on your smartwatch to click a photo



Tap on this icon to find your phone. Once enabled, your phone will start ringing and vibrating. Tap again to stop it. Note: Your smartwatch should be connected to your phone via

Bluetooth and within its range for this feature to work.



### SETTINGS Watch Faces Tap on this icon to change your watch face.



Tap on this and adjust the screen sleep time

Tap on this to choose the ringtone and put the watch on silent











Tap on this to adjust vibration levels from strong, soft and



Tap on this to turn on the Do Not Disturb mode.



You can access daily activity, SpO2, Heart rate, sleep, phone and notifications.

You can access DND, Alarm, Find my phone, Brightness, and Settings

SWIPE LEFT OR RIGHT TO ACCESS ALL DATA.

Tap on this to enable the voice assistant feature and give the

Note: Make sure the watch is connected with the app

SWIPE DOWN FOR SHORTCUT MENU

SWIPE UP TO ACCESS THE LIVE SCORE

Short press the side button to go to the previous tab.





### Screen type Battery capacity Net weight



Regularly clean your wrist and the strap of the smartwatch, especially after sweating during the other end of the product.

For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then

Do not wash the strap with a household cleanser. Please use soap less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.

## MAINTENANCE:

Bluetooth version

Charging time

Working time

Water Resistance

Frequency band

Working temperature

exercise or being exposed to substances such as soap or detergent, which may get stuck on