




# Airdopes 171

## Twin Wireless Ear-buds

Get ready to immerse yourself in musical bliss with your very own pair of boAt Airdopes 171. Please consider this manual as your guiding map towards the shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual; also, you may refer to the same at times when you face any sort of difficulty in future.

- In the box**
- 1 1x pair of Ear-Buds
  - 2 1x Charging Case
  - 3 2x Pairs of Ear Caps
  - 4 1x Charging Cable
  - 5 1x User Manual



### Power On (First Time User)

**Step 1:** To automatically switch the earbuds on (Smart Power On) simply take them out from the charging case OR To manually switch the earbuds on (Manual Power On), Long Press the Multi-Function Button (\*MFB) on both earbuds for 3 seconds until the LED starts to glow green for about 1 second.


**Step 2:** Both the earbuds will automatically pair with each other. The earbuds will enter into the Connection Mode.

### Connection Mode

**Step 3:** Turn on the Bluetooth functionality on your phone/media device and scan

**Step 4:** Search for 'Airdopes 171' and pair accordingly. Enter '0000' as the passkey if asked. Congratulations! Your earbuds are now connected successfully via Bluetooth

**Note:** Airdopes 171 remembers previously connected devices; once switched on, the ear-buds automatically reconnect to the previously connected device.



### Single Earbud Usage


**Step 1:** Please note that both the earbuds can be used in mono mode. Use either of the two options; Smart Power On or Manual Power On for switching on the desired earbud

**Step 2:** The selected earbud will automatically enter the connection mode.

**Step 3:** Turn on Bluetooth on your phone/media device and search for 'Airdopes 171' to connect


### Notes:

- To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, hence enabling Stereo usage
- You cannot skip tracks or return to the previous tracks in Mono mode



### LED Indicators / Functionalities

- 2 Seconds** Long Press the Multi-Function Button (\*MFB) on either earbud for 2 seconds to activate the voice assistant / Reject incoming calls
- 3 Seconds** Manual Power ON: Long press the MFB for 3 seconds on both Left and Right earbuds for switching them on until the LED light begins to flash in green.
- 5 Seconds** Manual Power OFF: Long press the MFB on either earbud for 5 seconds until the red indicator LED blinks before earbuds getting turned off.
- 10 Seconds** Factory Reset: Long press both the MFBs for up to 10 seconds to do Factory reset, which is indicated by the blinking of green and red Led lights.




### Charging The Earbuds

**Step 1:** Please insert the earbuds back inside the charging case in correct orientation.

**Step 2:** Red LEDs in the case indicate that the earbuds are being charged. Once fully charged the LED turns into green for 1 minute.

**Step 3:** Once the earbuds are fully charged, the charging case automatically switches off to save power.

**Note:**  
• Before using the ear-buds for the first time, it is recommended to fully charge the ear-buds. Also, please keep the lid of the charging case closed while charging and use a 5V/2A adaptor.




### Charge The Case

**Step 1:** To charge the case, plug one end of the charging cable into the case and the other end into a USB port.

**Step 2:** Red LED lights indicate that the charging case is being charged. Once the charging case gets fully charged, the LEDs turn into white.

**Note:** The LED lights located on the charging case indicate the battery status of the case.



Battery Level	LED
≤ 60%	Solid Red
60%~95%	Solid Green
≥ 95%	Solid White

### Basic Functions

- Voice Assistant: Long press the Multi-Function Button (\*MFB) on either earbud for 2 seconds to activate voice assistant
- Answer/Hang Up Call: Single press the Multi-Function Button (\*MFB) on either earbud to answer an incoming call and once again to hang up an ongoing call
- Reject Call: Long press the Multi-Function Button (\*MFB) on either earbud for 2 seconds in order to reject an incoming call
- Play/Pause Music: Single press the Multi-Function Button (\*MFB) on either earbud to play a song or to pause one
- Next Track: When playing music, double press the right earbud's Multi-Function Button (\*MFB) in order to skip to the next song on the playlist
- Previous Track: When playing music, double press the left earbud's Multi-Function Button (\*MFB) in order to return to the previous song on the playlist

• Three Way Calling: Double press the MFB to switch between active call and held call (when a call is received during an ongoing call, the initial call gets on hold)

• Crystal Mode: Airdopes 171 offers Crystal Mode for the ambient sound near you. You can hear the ambient sound clearly even while listening to the earbuds. Tap right earbud's MFB three times to turn on Crystal Mode, and again to turn it off.

Note: Volume cannot be controlled via earbuds and can only be adjusted via phone/media device.

### Voice Assistant

**Step 1:** Long press the Multi-Function Button (\*MFB) on either earbud for 2 seconds to activate voice assistant

**Step 2:** The respective voice assistant screen pops up and you may place your commands at ease

**Tips:** You may try the following commands,

- What is the weather?
- Play a song
- Where are The Pyramids located?



### Smart Power Off

**Step 1:** After usage, remove both the earbuds from your ears


**Step 2:** Place the earbuds back into the charging case in correct orientation

**Step 3:** The earbuds will automatically switch off (and enter into charging mode)

### Manual Power Off

**Step 1:** Long press the MFB on either earbud for 5 seconds until the red indicator LED blinks before earbuds getting turned off, in order to manually switch off the earbuds. Please note that this powers off both the earbuds

**Step 2:** Please keep the earbuds back into the charging case to charge the earbuds



### Factory Reset


Perform the Factory Reset in case you face any difficulty while operating your Airdopes 171

**Step 1:** Please remove the pairing record of Airdopes 171 from your phone or media device.

**Step 2:** Power off the earbuds, long press both the MFBs for up to 10 seconds or until LEDs blink red and green thrice.

**Step 3:** Keep the earbuds back inside the case in correct orientation and close the lid.

**Congratulations! Your Airdopes 171 has been reset and ready to establish connection again.**



### Common Problems with Solutions

#### If only one earbud is functioning:

- If one earbud is not working
- If earbuds are not in connection/scan mode
- If earbuds disconnect during phone call
- If there are other exceptions in usage

**Advisable:** The earbuds start at a 100% volume and it may need to be reduced when the earbuds are switch on at first. This can be done by using the volume control on the phone/ media device.

#### If earbuds are not in scan mode :

- If only one earbud is functioning: Simply insert the earbuds back into the case and take them out or perform the Factory Reset
- If earbuds are not in scan mode: Simply insert the earbuds back into the case and take them out or perform the Factory Reset

### Troubleshooting

Potential Problem	Solution
If one earbud is not working	Perform the Factory Reset
If earbuds are not in connection/scan mode	Perform the Factory Reset
If earbuds disconnect during phone call	Charge the earbuds or perform the Factory Reset
If there are other exceptions in usage	Place the earbuds back into the charging case and try using them again or perform the Factory Reset

**Charging norms & Precautionary Guidelines:**

1) Charger/Brick/Adapter	: 5V/2A
1) Cable/Wire	: Standard Cable (35 Strands @0.10mm diameter/strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.

### Specifications

Bluetooth Version	V5.0
Water Resistance	IPX4
Standby Time	70 Hours
Transmission Range	10m
Driver Size	6mm
Bluetooth Profile	HSP/ HFP/ A2DP/ AVRCP
Frequency	20Hz-20KHz
Battery Earbuds	43mAh x2
Battery Charging Case	380mAh
Charging Time	2 Hours
Talk Time/ Music Playtime	Up to 3 Hours per Charge and Additional 10H with Case
Charging Technology	ASAP Fast Charge Technology

### Warning

- Please follow the instructions to operate
- Please charge the ear-buds with input power below 5V/2A in order to protect the battery
- Please don't use the ear-buds in extreme temperatures
- Please don't use the product near water
- Please keep the product away from heat sources, as the heat may damage it
- Don't jam the ports such as charger port, LED port, etc.
- It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the ear-buds' service life
- Never disassemble or modify the device to avoid any permanent damage or danger
- Do not use the device during a thunderstorm to avoid irregular function or risk of electric shock
- Don't use harsh chemicals to clean the device

