

# MANUAL SETUP GUIDE

**boat**  
plug into nirvana

- WHATS IN THE BOX
- POWER ON/OFF
- CONNECTION MODE
- LED INDICATORS
- SINGLE EARBUD USE
- CHARGING
- FUNCTIONS
- VOICE ASSISTANT
- FACTORY RESET

## Airdopes 481 Twin Wireless Ear-buds

Get ready to ride the waves of Nirvana with your all new Airdopes 481. Please think of this manual as your map. Knowledge of Bluetooth and device connection is essential for the steering of this boAt. Therefore, we strongly advise that this manual is thoroughly read before beginning use, and referred to when in times of difficulty. We hope you're ready to Plug Into Nirvana.

**Airdopes 481**  
Twin Wireless Ear-buds

## Basic Functions

- Voice Assistant- Long Press the Capacitive Touch Control for 2 seconds to activate voice assistant.
- Answer/Hang up phone call- Tap the Capacitive Touch Control once to answer any incoming call and once again to hang up once done talking.
- Rejecting phone calls – Press and hold the Capacitive Touch Control for 2 second to reject an incoming call.
- Play/Pause – Tap the Capacitive Touch Control to play/pause music at your convenience.
- Next Track - When playing music, double tap the right earbuds Capacitive Touch Control to play the next track.
- Previous Track - When playing music, double tap the left earbuds Capacitive Touch Control to play the previous track.
- Volume up / Volume down- The volume cannot be changed from the earbuds, the volume will have to be adjusted via the connected device.

## Voice Assistant

STEP 1 : Long Press the CTC on either Left or Right Earbud for 2 Seconds to Activate Google / Siri Voice Assistant.

STEP 2 : Google / Siri Assistant Screen will pop up & you may command at ease.

TIPS: You may try the following commands

"What is the weather?"  
"Open Camera."  
"Play my Playlist"

Please Note: The Volume can not be controlled via your Earbuds, and can only be adjusted through your device.

## In the box

- 1x Airdopes 481
- 1x Charging Case
- 1x USB charging cable
- 2x pairs of additional earmuffs (S & M & L)
- User Manual

## Product Overview

- 1 CTC (Capacitive Touch Control)
- 2 Indicator light
- 3 Charging contact point
- 4 Charging Case indicator

## Power ON (First time user)

STEP 1 : Take out the Earbuds out of the Charging Case.

STEP 2: Please wait, Both Earbuds will automatically pair to each other. Blue/Red LED will blink for 1 seconds & automatically connect to each other.

This "BLUE / RED LIGHTS" means that it has gone into Connection Mode.

LED Indicators will blink on the left Earbud

## IWP (INSTA WAKE N' PAIR) TECHNOLOGY


The next time you when you open the lid of the case, our IWP (Insta Wake N' Pair) Technology enables the earbuds to power on automatically and get connected to the previously paired device.

- Notes:
- Pairing mode lasts for 3 minutes. If the pairing time is missed then you will need to reconnect the ear-buds and follow the above mentioned procedure
  - Airdopes 481 remembers previously connected devices; once switched on, the ear-buds automatically reconnect to the previously connected devices

## Connection Mode

STEP 3: Turn on bluetooth on your device & then scan.

STEP 4: Search for "Airdopes 481" and pair accordingly. Congratulations, your earbuds are now connected successfully.



Enter the password "0000" if asked for, and connect the earbuds to your device.

STEP 5: You may now enjoy your music or any other entertainment form factor

"CTC" Stands for Capacitive Touch Control.

NOTE: If the earbuds don't automatically Power On when taken out of charging case.  
STEP 1: Long Press CTC on left earbud first, then Long Press CTC on right earbud. This will power on both the earbuds. Wait for BLUE / RED LIGHTS on the left/right earbud. This "BLUE / RED LIGHTS" means that it has gone into Scan Mode.


## LED Indicators / Functionalities

2 Seconds Long Press CTC on either earbud for 2 Seconds to activate Voice Assistant. / Reject incoming Calls.

3 Seconds Manual Power ON: Blue/Red Lights will Blink.

5 Seconds Manual Power OFF Red LED will Blink for 1 Second

3 Taps Factory Reset: When power off & the earbuds are inside the case, tap the CTC on both earbuds 3 times.



NOTE: Factory Reset will remove all device profiles saved on the Airdopes 481. Refer To Page 12.

## Single Earbud Use


STEP 1 : At this stage your earbuds are in stereo mode & connected to your bluetooth device.

STEP 2 : Simply remove right/left earbud from your ear.

STEP 3 : And, place the Right/Left Earbud back into the Charging Case.

STEP 4 : Congratulations, you are now using mono/solo mode.

NOTE: Both Earbuds are Master Earbud, Single Earbud use will function on Both earbuds.




NOTE: To switch to stereo mode, simply take out the left/right earbud out of the case & place it in your ear. The left/right earbud will automatically power on & pair with your left/right earbud hence enabling it for stereo usage.

## Charge The Earbuds

• Put the Airdopes 481 back into the charging case in their correct orientation.

• A red light on the earbuds will indicate they are still being charged. This light will go off once the earbuds have been completely charged.

• When both two earbuds are fully charged, the carrying case will switch off to save power.



## Charge The Case

Warning: please do not charge the carrying case with "9V" or "12V" output. Otherwise, it may cause damage to the case.

• To charge the case, plug in the USB cable and connect it to any USB port.

• The 4 lights aligned vertically in the center of the charging case indicate the charge/battery status.

• 4 lights are illuminated for 60 seconds once the case has been completely charged

• The earbuds can be charged a total of 3 times if the case is at full battery.

## Smart Power Off

Your AirDopes 481 Earbuds will automatically Power On once taken out of the Charging Case. To Power Off follow below steps.

STEP 1 : After use, remove both left and right earbuds from your ear.  
STEP 2 : Place & put back both the earbuds into the Charging Case.  
STEP 3 : If LED is showing, it means it is charging.


## Manual Power Off:

STEP 1 : If both earbuds are on, long Press either left or right earbuds for 5 Seconds to manually power off the Earbuds. Please note, this will power off both the earbuds.

STEP 2: Place them back into the charging case to charge the earbuds.

## Factory Reset/Solution:

Perform below tasks if you ever face any difficulties with your Airdopes 481.



## Performing a Reset:

Perform the Factory Reset in case you face any difficulty while operating your Airdopes 481

Step 1: Place both the earbuds back into the charging case in correct orientation to switch them off

Step 2: Triple tap the capacitive touch control on both earbuds to perform the Factory Reset. Once done, it gets indicated by alternate red and blue LED flashes


Step 3: Shut the lid of the charging case and then re-open it again

Step 4: Once you take the earbuds out from the charging case, they automatically restart

Congratulations! Your Airdopes 481 has been Reset

## Common Problem With Solution

If one side working only:



If one side only working, then simply put back both earbuds in case or perform "Factory Reset".

If Earbuds not in scan mode:



If Earbuds not in Scan mode (No Red/Blue LED blink on left/Right Earbuds) Simply put back both the earbuds in case and take out again or perform "Factory Reset".

## Troubleshooting

Potential Problem	Solution
Right Earbud disconnects during phone call	Place the earbuds in the charging case and then try using them again. It will connect automatically.
Left & Right Earbuds are not pairing	Try re-setting the device.
About 20 seconds delay or easy disconnect for Right earbud	Power off, then switch on once more
Occasional disconnect and recover minutes later	Power off, then switch on once more
If there are other exceptions in use	Place the earbud's in the charging case and then try using them again. If this does not work, try re-setting the device

## Specifications

Speaker Size	6mm	Charge Time For (Includes Charging Case)	About 2 Hours
Sensitivity	100±3db	Stand by Time (Includes Charging Case)	About 300 Hours
Impedance	16Ω		
Response Range	20Hz-20KHz		
Bluetooth Version	Version 5.0	Music/Play/Talking Time:	About 4 Hours (At 60% Volume)
Waterproof Grade	IPX 5	Provides 3 Charge Cycles.	
Earbud Battery	Li-Polymer Battery 243mAh		
Charging Base Batt.	400mAh		
Earbud Charge Time	About 1.5 Hours		

## Charging norms & Precautionary Guidelines:

1) Charger/Brick/Adapter	: 5V/2A
1) Cable/Wire	: Standard Cable (35 Strands @0.10mm diameter/strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.

## Cautions:

1. Please think of this manual as your map. Knowledge of Bluetooth and device connection is essential for the steering of this boAt. Therefore, we strongly advise that this manual is thoroughly read before beginning use, and referred to when in times of difficulty.
2. Please do not let the earbuds come into contact with sharp edges, uneven surfaces, and metal parts, in a manner that can lead to some form of permanent external or internal damage.
3. Please don't dismantle the product in any way, it can lead to a fire or electrical breakdown and even completely damage the product. As this is extremely unsafe, we ask that any maintenance or servicing of the headphones is done only through a qualified service provider/manufacturer.
4. Please do not remove the battery by yourself, this is a task meant to be managed by a service provider/manufacturer. Replacing the current battery with an ill-fitting set can result in a fire or electric hazard, therefore it is strongly advised against.
5. Please clean the earbuds with the utmost of care with only a damp soft cloth, if cleaning is required. Please do not use any oily volatile liquid. In addition, ensure that the Headsets are kept away from extremely hot or cold substances.
6. To avoid damage to your hearing, make sure that the volume on your music player is at an appropriate level when you are plugging into Nirvana. After wearing the earbuds, gradually turn up the volume until you reach a comfortable listening level. Exposure to any noise levels at or above 85 dB can gradually lead to a loss of hearing. Therefore, listening sessions that are at higher volumes should not be for too long. If you are planning to use the earbuds for extended periods of time, it is safer to keep the volume at a low level.
7. Any damage to the earbuds that is NOT a manufacturing issue will make the products warranty null and void. Please take the greatest care of your headphones to ensure that no such occurrences take place.
8. Do not use earbuds when it is unsafe to be wearing them, such as while operating a vehicle, crossing a street, or during any activity where full awareness of your surroundings is required. This is because it is dangerous to drive while wearing headphones as it decreases your ability to hear sounds like another car's horn or an emergency vehicle's sirens. Therefore, please avoid wearing your Headsets while driving.

Advisable: The earbuds will start at a 100% volume, and may need to be reduced when first switched on. This can be done using the volume control on your bluetooth

# ROCK INTO YOUR RHYTHM

**boat**  
plug into nirvana



**Airdopes 481**  
Twin Wireless Ear-buds