



### Operation Guide

1. While attempting to use Bluetooth pairing, ensure that the device and headphones are within 1 meter of each other
2. To disconnect Bluetooth, hold the play button for up to 4 seconds
3. Bluetooth indicator status: A constantly flashing blue light will indicate that the headphones are in pairing mode, if the blue light is flashing slowly then this means that the headphones are paired.
4. Search for and select "boAt 900 Wireless" from the list of options that appear on the Bluetooth supporting device.

### Answer Calls

1. Tap the phone icon on the headphones to answer an incoming call
2. Double tap the phone icon on the headphones to reject an incoming call
3. During a call, press the pause icon to disconnect and end the call

### Play/Pause

When playing music, press the Play/Pause button to stop or start tracks

### Last number Redial

When the headphones are connected with Bluetooth, press the phone icon as a shortcut to redial the previous number.

### Volume Control & Song Switch

1. When listening to music, press and hold the "+" button to skip to the next song, to increase the volume tap the "+" to adjust it to your preference
2. When listening to music, press and hold the "-" button to go back to the previous song, to decrease the volume tap the "-" to adjust it to your preference

### Important Safety Instructions

1. Carefully read and follow all steps provided
2. Do not lose these instructions
3. Pay attention to all warnings
4. Clean with a dry cloth only
5. Install in accordance with the instructions, do not block any ventilation openings
6. Follow all applicable laws pertaining to transporting, shipping and the disposal of batteries. For details on recycling lithium, lithium phosphate and lithium ion batteries, contact a government recycling agency, or your waste disposal service.
7. Prevent the allow the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and any exit points from the apparatus
8. Only use attachments/accessories specified by the manufacturer

### Important Safety Instructions (Contd)

9. Do not charge the headphones during lightening, storms or when unused for long periods of time
10. Refer all servicing to qualified service personnel. Servicing is required when the headphones have been damaged in any way, such as damage to the power supply cord and plug, or physical damage from being dropped. In the event of exposure to rain, moisture or any other liquids causing the headphones to not work properly; please send the headphones for servicing.
11. Do not listen at high volumes for prolonged periods of time, as it can produce sound levels which can be harmful to hearing.
12. These are passive noise cancellation headphones, and must NOT be used while operating a vehicle, or any other circumstances requiring full use of the senses. Users assume all risks associated with the use of this product.



### Specification

- Impedance: 32 Ohm
- Frequency response: 20Hz -20KHz
- Max power: 20mW
- Drivers: 40mm
- Weight: 145g
- Bluetooth transmission distance: Approx. 10 meters
- Music time: Up to 8 hours
- Charging time: 2.5 hours


### Product Features

- Bluetooth: Anyka 5.0 Chip delivers rich sound details for high quality audio experience.
- Ergonomic Foldable & Stretchable Design for Comfortable Fit.
- High-quality PU Material

### Product Accessories

- User manual
- Charging cable
- Audio cable
- Bluetooth Headphone
- Warranty Card

### Product Overview



**boat**  
plug into nirvana



**900**  
Wireless Headset

User Manual

Jacqueline  
Fernandez