


Please think of this manual as your map. Knowledge of Bluetooth and

device connection is essential for the steering of this boAt. Therefore, we

strongly advise that this manual is thoroughly read before beginning

## **Package Contents**

- 1. boAt 100 Wireless x 1 2. User Manual x 1
- 3. Extra Eartips: S/L x 1
- 4. Micro USB-Cable x 1 5. Warranty Card x 1



### Components

- 1. ABS front and back cavity
- 2. Volume down/Previous track
- 3. LED (Red light /Blue light)
- 4. Multifunction Button 5. Volume up/Next track
- 6. Charge port

- - 9. Slide buckle

7. Neckband

8. TPF cable

#### **Functions**

- (1) Power on: When switched off, press and hold the multifunction button for 2 seconds. The red and blue LEDs will begin to flash for 1 second.
- (2) Power off: In any mode, press and hold the multifunction button for 3 seconds. A voice tone will confirm the same. The red and blue LED's will flash for 1 second before the device will turn off.
- (3) Play/Pause: Tap the multifunction button once to play/pause music.
- (4) Volume up: Tap the volume "+"buttons in steps to increase the volume. A beep will indicate maximum volume.
- (5) Volume down: Tap the volume "-"button in steps to decrease the volume. A beep will indicate minimum volume.
- (6) Answer/End call: Tap the multifunction button once when answering or ending a call to complete the action.
- (7) Reject call: Press and hold the multifunction button for 2 seconds when receiving a call to reject it. A beep will indicate this.
- (8) Previous Track: To go to the previous track, press and hold the "-" button for
- (9) Next Track: To skip to the next track, press and hold the "+" button for 2
- (10) Clear paired device: Press and hold the volume buttons together for 5 seconds to reset the list of devices the earphones have been connected with. The red and blue lights flash thrice simultaneously.
- (11) Pairing Mode: The earphones automatically enter pairing mode when switched on. The Red and Blue LED light will alternately flash (3 times) to

#### To Pair with Bluetooth

- (1) When switched off, press the multifunction button for 5 seconds to switch the earphones on. The earphones will automatically enter pairing mode with a prompt and the LED light will flash red and blue lights flash to indicate this.
- (2) Open Bluetooth on your device and search for "boAt 100 Wireless" in the list of available devices
- (3) Choose "boAt 100 wireless" from the list and enter the pairing password "0000" to establish Bluetooth connectivity. A voice prompt "connected" will be heard to confirm the connection. The blue light flashes twice every 4 seconds while connected.
- (4) If the pairing fails, the blue light flashes once every 2 seconds. The earphone will automatically shut down if not paired within 5 minutes of being on.

#### To Charge

Use a micro USB charging cable to charge the earphone.

- (1) Low Battery: The remaining talk time is less than 10 minutes. There will be a 'tone' and a reminder every minute.
- (2) Charging: The red light is steady (please note that the earphone cannot be turn on when charging).
- (3) Fully charged: the blue light is steady.

# **Specifications**

 Sensitivity: 102±3dB • Impedance : 16  $\Omega$ 

• Frequency response: 20-20KHz

use, and referred to when in times of difficulty.

Speaker size: 10mm

• Neckband length: 300mm • Cord length: 220mm±2cm • Bluetooth solution: BK3266

• Bluetooth version: 5.0

• Battery: Lithium-ion battery/3.7V/320mAh

• Charging time: 1.5-2 hours

• Music/Play/Talking time: Up to 15 hours

 Standby time: about 240 hours • Transmission range: about 10m

Support agreement: HSP/ HFP/ AVRCP/A2DP

• IPX RATING: 4

# Safety Cautions

- Please don't dismantle the product in any way, as this can lead to a fire or electrical breakdown and completely damage the product. As this is extremely unsafe, we ask that any maintenance of servicing of the earphones is done only through a qualified service provider/manufacturer.
- Please do not remove the battery by yourself, this is a task meant to be managed by a service provider/manufacturer. Replacing the current battery with an ill-fitting set can result in a fire or electric hazard, therefore it is strongly
- Please clean the earphones with the utmost of care with only a damp soft cloth, if cleaning is required. Please do not use any oily volatile liquid. In addition, ensure that the earphones are kept away from extremely hot or cold
- Any damage to the earphones that is NOT a manufacturing issue will make the products warranty null and void. Please take the greatest care of your earphones to ensure that no such occurrences take place.
- Do not use earphones when it is unsafe to be wearing them, such as while operating a vehicle, crossing a street, or during any activity where full awareness of your surroundings is required. This is because it is dangerous to drive while wearing earphones as it decreases your ability to hear sounds like another car's horn or an emergency vehicle's sirens.
- To avoid damage to your hearing, make sure that the volume on your music player is at an appropriate level when you are Plugging into Nirvana. After wearing the earphones, gradually turn up the volume until you reach a comfortable listening level. Exposure to any noise levels at or above 85 dB can gradually lead to a loss of hearing.

#### WARRANTY

boAt 100 wireless comes with a one year all India warranty.

Phone: +91-22-30147239, Email: info@imaginemarketingindia.con

Warranty Card	
Customer Name :	
Product Name :	Model No.:
Address:	Date of Purchase:
Dealer Name :	Phone No.:
For Service please contact :- Imagine Marketina Pvt. Ltd. 255, Guru Gob	ind Ind Est Jav Coach, Goreagon East, Mumbai 400063,

#### CONNECT WITH US ON



boAt-lifestyle.com



facebook.com/boat.nirvana



instagram.com/boat.nirvana youtube.com/boAt-nirvana

