



Airdopes 711
Twin Wireless Ear-buds

Get ready to immerse yourself in musical bliss with your very own pair of boAt Airdopes 711. Please consider this manual as your guiding map towards the unparalleled shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual; also, you may refer to the same at times when you face any sort of difficulty in future.

Package Contents

- 1) 1x boAt Airdopes 711
- 2) 1x Charging Case
- 3) 1x Type-C Cable
- 4) 2x Pairs of Additional Earmuffs (Small & Large)
- 5) User Manual

Overview

- 1) CTC (Capacitive Touch Control)
- 2) Battery Indicator
- 3) MFB (Multi Function Button)

Power On (First Time User):

Step 1: To switch the earbuds on (Smart Power On) simply open the lid of the carry case
OR
Long press the MFB (*Multifunction Button) for 3 seconds to manually power on the earbuds

Step 2: Both the earbuds will automatically enter pairing mode indicated by rapid white LED flashes

Step 3: Turn on the Bluetooth functionality on your phone/media device and scan

Step 4: Search for 'Airdopes 711 right/left' and pair accordingly. (The connected earbud is the master earbud)

Step 5: Once the Master earbud gets connected, a connection window for the other earbud also pops up. Pair with the same to establish the complete connection

Congratulations! Your earbuds are now connected successfully via Bluetooth

Power On (Subsequent Usage):

- The next time you when you open the lid of the case, our IWP™ (Insta Wake N' Pair) Technology enables the earbuds to power on automatically, get connected and enter into the connection mode

Note:

- Pairing mode lasts for 5 minutes. If the pairing time is missed then you will need to reconnect the ear-buds and follow the above mentioned procedure
- Airdopes 711 remembers previously connected devices; once switched on, the ear-buds automatically reconnect to the previously connected devices

Single Earbud Usage

Step 1: Please note that both the earbuds can be used in mono mode. Use Smart Power On for switching on the desired earbud

Step 2: The selected earbud will automatically enter the connection mode indicated by white LED flashes

Step 3: Turn on Bluetooth on your phone/media device and search for 'Airdopes 711 right/left' to connect

Notes:

- To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, hence enabling Stereo usage
- You cannot skip tracks or return to the previous tracks in Mono mode

LED Indicators / Functionalities

- 2 Seconds:** Long press the CTC (*Capacitive Touch Control) for 2 sec on either earbud to activate voice assistant
- 3 Seconds:** Long press the MFB for 3 sec to manually Power On
- 5 Seconds:** Long press the MFB for 5 sec to manually Power Off
- 3 tap MFB:** 3 tap MFB button on both earbuds for Factory Reset, White LED flashes once

Charging the Earbuds:

Step 1: Please insert the earbuds back inside the charging case in correct orientation.

Step 2: A solid orange LED will indicate that the earbuds are being charged. Once fully charged the LED turns off

Step 3: Once the earbuds are fully charged, the charging case automatically switches off to save power.

Note:

- Before using the ear-buds for the first time, it is recommended to fully charge the ear-buds. Also, please keep the lid of the charging case closed while charging
- When the battery is less than 10%, solid orange LED indicates the same. When the battery is more than 10%, solid white LED indicates the same

Charge The Case:

Simply place the charging case of Airdopes 711 on the wireless charging pad. Or, you can use the USB Type C cable to charge the case. The charging gets indicated by white LED on charging case.

• Remaining Battery LED Indicator – A 5 second display while one opens and closes the case

Remaining battery 0%-10%	Solid Orange LED
Remaining battery 10% – 100%	Solid White LED

• Charging LED Indicator

Power is 0% - 99% when charging	White LED flashes
Full charge	Solid White LED

Note: The LED lights located on the charging case indicate the battery status of the case.

Basic Functions:

- Voice Assistant:** Long touch the CTC on either earbud for 2 seconds to activate the voice assistant
- Answer/Hang Up Call:** Single tap the MFB on either earbud to answer an incoming call and once again to hang up an ongoing call
- Reject Call:** Long touch the MFB for 2 seconds to reject incoming calls
- Play/Pause Music:** Single tap the CTC on either earbud to play or pause a song
- Next Track:** When playing music, double tap the right CTC to skip to the next song
- Previous Track:** When playing music, double tap the left CTC to return to the previous song
- Crystal Mode:** Airdopes 711 offers Crystal Mode for the ambient sound near you. You can hear the ambient sound clearly even while listening to the earbuds. Tap the right earbud's CTC three times to turn on Crystal Mode, and again to turn it off.

Note: Volume cannot be controlled via earbuds and can only be adjusted via phone/media device

Voice Assistant:

Step 1: Long touch the CTC on either earbud for 2 seconds to activate the smart voice assistant

Step 2: The respective voice assistant screen pops up and you may place your commands at ease

Tips: You may try the following commands,

- What is the weather?
- Set a reminder

Note: Siri doesn't wake when music is playing in the background. Kindly exit music player then try again.

Smart Power Off

Step 1: After usage, remove both the earbuds from your ears

Step 2: Place the earbuds back into the charging case in correct orientation

Step 3: The earbuds will automatically switch off (and enter into charging mode)

Manual Power Off: Long press the MFB for 5 seconds to manually power off the earbuds

Factory Reset:

Perform the Factory Reset in case you face any difficulty while operating your Airdopes 711

Step 1: When both the earbuds are turned on and outside the case, Triple tap the MFB button on both earbuds to perform Factory Reset, which gets indicated by the flashing of white LED once.

Step 2: After the white LED flashes once, place back the earbuds inside the case and shut the lid

Step 3: Once you open the lid, the earbuds get reset and ready to pair. Congratulations! Your Airdopes 711 has been Reset

Common Problems with Solutions:

If only one earbud is functioning:

If only one earbud is functioning: Simply insert the earbuds back into the case and take them out or perform the Factory Reset

If earbuds are not in scan mode:

If earbuds are not in scan mode: Simply insert the earbuds back into the case and take them out or perform the Factory Reset

Specifications

Bluetooth Version	V5.0
Water Resistance	IPX5
IWP Technology	Yes
Dual Microphone	Yes
Wireless Charging	Yes
Crystal Mode	Yes
Music Playtime	Up to 10H per Charge, Up to 40H with Case
Standby Time	127 Hours
Battery	55mAh *2 earbuds, 470mAh case
Transmission Range	10m
Driver Size	2*6mm
Bluetooth Profile	HFP/HSP/A2DP/AVRCP
Frequency	20Hz-20kHz
Chip solution	QUALCOMM*
CODEC	Qualcomm* aptX**
Noise Isolation	Qualcomm* cVc 8.0**
Charging Time	Earbuds: 60 minutes; Case: 1.5-2 hours
Charging Type	Type C and Wireless Charging
Product Weight	5.7g Earbud

Charging norms & Precautionary Guidelines:-

1) Charger/Brick/Adapter	: 5V 2A
2) Cable/Wire	: Standard Cable (35 strands @0.10mm diameter/ strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.

Troubleshooting

Potential Problem	Solution
If one earbud is not working	Perform the Factory Reset
If earbuds are not in connection/scan mode	Perform the Factory Reset
If earbuds disconnect during phone call	Charge the earbuds or perform the Factory Reset
If there are other exceptions in usage	Place the earbuds back into the charging case and try using them again or perform the Factory Reset
If the In-Ear Detection or Touch Controls don't seem to respond	After long usage, residual stains and perspiration can affect the in-ear detection area or touch control area, please use a clean cloth to wipe those areas softly

Warning:

- Please follow the instructions to operate
- Please don't use the ear-buds in extreme temperatures
- Please don't use the product near water
- Please keep the product away from heat sources, as the heat may damage it
- Don't jam the ports such as charger port, LED port, etc. It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the ear-buds' service life

Advisable: The earbuds start at a 100% volume and it may need to be reduced when the earbuds are switched on at first. This can be done by using the volume control on the phone/ media device.

Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries. aptX and cVc are trademarks of Qualcomm Technologies International, Ltd., registered in the United States and other countries.