SPECIFICATIONS

Headphone Type	Bluetooth Headphones
Driver Size	40mm
HD Sound	Yes
THD	≤1% at 1kHz
Frequency Range	20Hz-20kHz
SNR	≥90dB
Bluetooth Version	V4.2
Bluetooth Profile	A2DP, AVRCP, HFP, HID, AVCTP, AVDTP, SPP
Bluetooth Range	10m
Battery Capacity	400mAh
Playing Time	Up to 15 Hours
Charging Time	2.5 Hours
Mic Sensitivity	-42dB
Charging Voltage	5V
AUX Connectivity	Yes

SAFETY PRECAUTIONS

- This is not a toy. The children are advised to use this under adult supervision.
- · Avoid exposing the device to extremely hot or cold temperatures.
- Avoid using the headphone for listening to full volumes to protect from hearing damage.
- · Please do not use the device under thunder storms.
- · Don't dismantle the product in any way.
- · Please don't clean the product using oily volatile liquid.

ANOMALIES & SOLUTIONS

A. Mobile can't search the headset

- Check if the Bluetooth headset is powered on or off (When powered on, the LEDs blink with red and blue colours alternatively)
- If it is powered on and the device still can't connect, then please reboot the Bluetooth device and the phone
- B. After connecting the headset with the phone, disconnection or noise occurs
- · This may be due to the low power of the headset. Please charge the Bluetooth headset
- There might be obstruction between the headset and the phone or the distance between them exceeds the maximum range for signal reception







Thank you for choosing the boAt Rockerz 560. This manual is meant to guide you through to the shores of Nirvana without much difficulty. Please think of this manual as your map. Knowledge of Bluetooth and device connection is essential for steering this boAt. Therefore, we strongly advise that this manual is thoroughly read before use, and referred to in times of difficulty.

PACKAGE CONTENTS

- 1 x boAt Rockerz 560
- 1 x Micro USB charging cable
- 1 x Audio Cable
- 1 x Manual
- 1 x Warranty Card

POWER ON: Press and hold the Power button for 3 seconds. The blue and red LED light will blink alternatively accompanied by a voice prompt "power on".

POWER OFF: Press and hold the Power button for 5 second. A voice prompt "power off" accompanied by quick flashes of red LED will indicate the device getting switched off.

BLUETOOTH CONNECTIVITY

- Turn on the Bluetooth in your phone and switch on Rockerz 560 by long pressing the Power button for 3 seconds
- 2. In case if the headphone is not in pairing mode, then don't release the button and keep on long pressing the Power button for turning on the Bluetooth pairing mode in the headphone, until the indicator starts blinking in blue and red colours alternatively.
- 3. Then, click on the headphones 'Rockerz 560' from the list of available devices after search.
- 4. If asked for a passkey, confirm the passkey '0000' on phone
- Once confirmed, the headphone and phone are connected via Bluetooth indicated by a slowly flashing blue indicator.

Note: If there's a connection history between the phone and the headphone, then they will automatically get reconnected in a working range.





BASIC FUNCTIONS

	Play	Short press the ► II once to play
Γ	Pause	Short press the ►II once to pause
Г	Volume Up	Press the ▶▶ button in steps to increase volume
Г	Volume Down	Press the ◀ ◀ button in steps to decrease volume
Γ	Next Track	Press and hold the ▶▶ button for skipping to next track
Γ	Previous Track	Press and hold the ◀ ◀ button for returning to the previous track
	Answer Incoming Calls	Single press the ► II button
Г	Hang Up Ongoing Calls	Single press the ► II button
	Reject Calls	Press and hold the ►II for 1 second
	Redial	Double press the ►II
	Charging	Connect the charger to the micro USB port; steady red indicator switches on while charging
Γ	Voice Assistant/Siri	Double press the Power Button

OTHER FUNCTIONS

- When Line In inserting is detected, switch to line in mode and disconnect Bluetooth. To connect again to the Bluetooth, pull out the line in and reboot.
- If there's no connection established when the Bluetooth is switched on then the device powers off automatically after a while.
- When the voltage is below 3.3V it makes a 'beep' alarm sound. Insert the power source and it works normally
 again
- Under voltage automatic power off occurs when the voltage is below 3.3V and the device powers off automatically. After recharging the device, press the power button to reboot.
- Intelligent charging mechanism offers a safe environment for the device and the LED indicators for a better way to charge your device.
- If you receive an incoming call during playing music, the music automatically disconnects. When the call is done and disconnected, the music starts to play automatically from where it left.
- You may double press the ►II button to redial the last contacted number.

CHARGING

- · Connect the charger to the micro USB port on the headset
- While charging the indicator light will turn into steady red
- · When the headphone is fully charged, the indicator switches off
- Use only authorized/company chargers for the headset, as unauthorized ones may damage the same and invalidate the warranty on the headset as well

CHARGING NORMS & PRECAUTIONARY GUIDELINES: -

- 1) Charger/Brick/Adapter: 5V 2A
- 2) Cable/Wire: Standard Cable (35 strands @0.10mm diameter/ strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.