







Insert the earbuds into your ear properly and adjust the ear

Pairing

Press and hold for

To enter pairing mode, press and hold the Multifunction Button for 2 seconds until the indicator begins to flash red and blue

Note: The headset will directly enter pairing mode the first time it is switched on. To enter pairing mode again, you need to follow the instruction illustrated above



After entering pairing mode, open Bluetooth and search for

Charging



When the battery level is low, you will see the indicator flash red and hear a voice prompt.

Factory Reset



While charging, press and hold the Multifunction Button until the indicator flashes red and blue alternately to factory reset the earphones

General Functions

Answer/End a call

When receiving an incoming call (the indicator will flash blue), press the Multifunction Button to answer the call and press it again to end the call once finished.



Reject a call 🕝

When rejecting an incoming call (the indicator will flash blue), press and hold the Multifunction Button until the call has been rejected.



Redial last number ...

If the earphones are connected to your device via Bluetooth, simply double click the Multifunction Button to redial the last contacted number.



Activate voice control

While connected, simultaneously press and hold the '+' and '-' volume buttons until you hear a beep meaning that the





Next/Previous track

To change the track, press and hold '+' to go to the next track and '-' to return to the previous track until the transition has



Use the '+' button to increase the volume and the '-' button to reduce the volume level while using the earphones.



Dual Pairing

Follow the pairing procedure to connect the earphones to the first device and then turn off the earphones as well as Bluetooth on

2. Switch the earphones back on, press and hold the Multifunction Button to enter pairing mode. Activate wireless Bluetooth search on the second device and select "boAt Rockerz 261" from the



3. Finally, open the wireless Bluetooth connection on the first device, and select "boAt Rockerz 261" to complete Dual Pairing



Multiple call handling

If the device is connected to multiple mobile phones, and you are already taking a call on one of the devices when the second mobile phone begins to ring, press the Multifunction Button to switch to the 2nd call, placing the first one on hold. One can continuously switch between the two calls using the Multifunction Button.

Play/Pause

When using the earphones, use the Multifunction Button to pause and play music.

Transfer voice between headset

Press and hold the Multifunction Button to transfer the call

Product Features



V4.1 wireless version, compatible with over

99% of mobile phones and tablets

Basic Parameters

Wire ess Version: V4.1 Chipset: CSR 8635 Charging Time: 1~2 hours Range: 10 meters Standby Time: 250 hours Charging Voltage: DC 5V

Wireless Profile: HFP/A2DP/ Talk Time: 7~9 hours HSP/AVRCP Notes: Playtime varies according to volume level and audio

For after-sales support, please contact our customer service with your order ID.

Warranty Terms & Conditions

1. During the warranty period of one year, if a product is not working or the components are of poor quality or production problems- the company will provide free maintenance and assist in the replacement

You must be able to demonstrate the purchase of the product, so please keep a proof of purchase with you.

3. The warranty does not cover damages caused by alteration of parts,

FAQ/Trouble shooting

Q: I have established connection with my smartphone, but there is no

A: Please make sure that you turn up the volume of both devices. Some smartphones requires you to setup the wireless headset as an audio output devices before sound is transmitted. Please see the instruction of your smartphone for details. If you are using a music player or some other wireless device, please make it so that it supports A2DP stereo music profile

Q: Why is the connection not stable and is cut out intermittently?

A: Please ensure that there are no objects between the earphones and your wireless device; please ensure there is no radio or Wi-Fi

Q: Can I use the earphones while it is charging?

A: No, the earphone can only be used while they are functioning on the current battery level, without charge.

Q: The headset is not responding, what should I do?

A: Please try to reset the headset (see the "factory reset" section for

Q: The sound is not very clear/ the caller cannot hear my voice clearly,

A: Please adjust the volume on your phone and earphones. Make sure there is no source of interference nearby and that the

Tips

1. Before using the headset, please read the manual carefully and keep it with you for future references.

2. The earphones need to be fully charged prior first-time use.

3. Please re-charge the earphones periodically, even if not in use for

4. Use only chargers made by a qualified manufacturer.

5. If the headset cannot be found on your phone, please confirm whether it is in pairing mode. If left connected for a long time, the headset will exit pairing mode. Please re-enter pairing mode to re-connect. If a procedure error takes place on your phone, please re-boot the device similarly please do the same with the earphones if a procedure error occurs on that end.

6. Never disassemble or modify your earphones for any reasons so as to avoid any danger or damage.

7. Do not use the earphones during a thunderstorm to avoid irregula function and to avoid the increased risk of electric shock.

8. Do not use harsh chemicals or strong detergents to clean the

9. Keep the earphones dry at all times.

Warranty Card

Customer Name:
Product Name:
Address:
Dealer Name:
Model No.:
Date of Purchase:
Phone No :

rservice piedse conflict ;-agine Marketing Pvt. Ltd, 255, Guru Gobind Industrial Estate y Coach, Goregaon East, Mumbai,Maharashtra - 400063. one: +91-22-30147239, Email: info@imaginemarketingindia.con



instagram.com/boat.nirvana

youtube.com/boAt-nirvana

