

Tap on this to set an alarm on your watch.



Tap on the remote music control icon on your watch to play music from your phone.

*Note: Some apps with different protocols might not work.



Click on this to start the stopwatch on your watch



Tap on this to turn your dial into a flashlight.



ULTIMA CALL MAX

Thank you for choosing the boAt Ultima Call Max as your fitness transformation companion.

Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as



PACKAGE CONTAINS

USB magnetic charging cable User Manual x1 Warranty Card x1

CHARGING THE WATCH

for 3-5 seconds.

Phone Call

Tap on this to enable phone calls



You can wake up the screen by lifting your wrist.

The smartwatch must be charged before initial use. It takes up to 2 hours to be fully charged. Connect and charge the watch with the image below as a reference, using 5V/2A adapter.



CONNECTING TO THE APP

1. Download the boAt Wearables app on your phone. Available on both App Store (iOS 12.0 and above) and Google Play Store (Android 7.0 and above)

Scan [QR CODE] (Also available on the watch)

2. Connect the device with the boAt Wearables app; ensure that the phone's Bluetooth as well as the GPS functionalities are turned on

3. Select Ultima Call Max on the home screen of the app and click pair to connect.

4. Once connected, you will get an alert to connect with UCALLMAXBT, click pair if need to receive or make calls from the watch

5. To use all features of your Ultima Call Max seamlessly, tap on 'yes' to the 'connection' and 'grant access' system prompt.

6. Disable battery optimization





Note: To ensure connectivity throughout your journey, make sure the app is allowed to run in the background of your phone at all times.

SYNCING YOUR SMARTWATCH TO THE APP

pair the watch.

Open the app on your phone.

Make sure your Ultima Call Max is connected to the app

Synchronization will start automatically once you enter the app interface.

Synchronize data at least once every day to avoid data loss in the watch.

NAVIGATING THROUGH THE FUNCTIONS

SWIPE UP FOR THE MAIN MENU

connect with Phone's Bluetooth.

Use a dialer to dial any number.

Click on this to check your daily activity data like step count,

Once paired you will get the pop-up on the app home screen to

Alternatively, you can go to phone's Bluetooth settings and pair

Note: Enable call alerts from the setting to get calls on the watch

"UCALLMAXBT" to start the calling feature on your watch.

Click on "pair" to connect with phone's Bluetooth.

Up to 10 contacts can be saved in the phonebook.

Call history will show the latest call details.



Wear the watch on your wrist, then click on the icon to start

purposes.

movement

Heart Rate Monitor

from 8 om at night to

which includes limited

10 am in the morning the next day.

measurements. You can also view the data on the app. Note: Measurements are for reference only and not for medical

Tap on the icon to review the sleep data of the previous night.

Once the asleep criteria are met, your smartwatch will start recording

Once you lie down and watch detects no movement for 30 minutes, it

You can check the data on the app only after the awake criteria is met.

For accurate sleep data recording, the sleep criteria have to be met

The awake criteria will be met only after it records some noticeable

will start recording, and will stop recording if it detects excessive

You can also track sleep scores on the boAt Wearables app.

movement, wrist positions and angles, and more.

earch for the app to connect keeps failing

martwatch also display those notifications.

My Bluetooth keeps getting disconnected

Maximum depth of water: 1.5m

3. Make sure the app is running in background

Keep the boAt Wearables app updated to the latest version

My Watch Ultima Call Max is receiving no alerts, texts, or phone calls

There is no obstacle in between the watch and the phone.

Will it be okay to take a bath wearing the Ultima Call Max?

Which functions of the Ultima Call Max need Bluetooth to work?

other wading or deep-water activities with high-speed water flow.

The IP68 water resistance will only work under the following conditions:



Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app. Note: Measurements are for reference only and not for medical

Check and enable notification functions of your phone and keep the phone and watch in

Also make sure your notification center of the phone is displaying messages. Only then will your

Make sure app is running in the background and battery optimization feature on the phone

and custom watch faces and Bluetooth calling need Bluetooth connectivity to work.

he watch isn't suitable for hot baths, hot springs, saunas, snorkelling, diving, water skiing and

Note: Make sure your phone system meets Android 6.0 and above and iOS 12.0 and above.



Choose from multiple sports mode like walking, running, cycling, skipping, Badminton, Basketball, football, climbing, tennis, rugby, golf, yoga, workout, dancing, baseball, elliptical machine, indoor cycling, free training, rowing machine.



Tap on any sport mode to start the activity, you can pre-set your goal as well for each activity. Press the side button to pause or stop the activity. If the activity is less than 3 mins, it will not be recorded.

Sync your smartwatch to the app to get the detailed analysis

Connect with the boAt wearables app to get daily weather updates on the watch

Tap on this icon to check your messages



command from the watch.

Camera Control Mode

shoto from your phone.



Click on the breath training icon to regulate your breathing with the instructions given to relax.

Tap on this to enable "Ok google" and "siri" on the app and give the

Note: Make sure the watch is connected with the app

Tap on the remote camera icon on your smartwatch to click a

*Note: Turn the camera on from your phone to use this feature.



Tap on this icon to find your phone. Once enabled, your phone will start ringing and vibrating. Tap again to stop it. Note: Your smartwatch should be connected to your phone via Bluetooth and within its range for this feature to work.



Tap on this to access a variety of games. Select from 2048, thunder battleship, young bird.



Tap on this to adjust the brightness, set the screen on time and enable wake gesture



Call BT Reset Tap on this to reset the call BT option

Tap on this to disable all notifications except alarms. Tap on this to choose from ring, ring and vibration and Vibration



Tap on this icon to enable the Eco mode. Vibration, wake gesture FCO Mode will be disabled and brightness will be minimum.



Shows the device details



WIPE DOWN FOR SHORTCUT MENU

You can access DND, Brightness, timer, camera control, flashlight,



WIPE RIGHT FOR WIDGET CONTROL

You can control the recently used activities here



SWIPE LEFT TO ACCESS SHORTCUT DATA You can access daily activity, phone call, heart rate monitor, SpO2,

sleep and add more activities.



ODUCT PARAMETERS: boAt Ultima Call Max

n type	2.0" HD Display
y capacity	280mAh
eight	44g
ooth version	BLE 5.1 + BT 3.0
ng temperature	-10°C - 50°C
ing time	2H around
ng time	up to 7 days in normal mode,
	up to 2 days on BT calling
Resistance	IP68
ency band	2402-2480Mhz

Regularly clean your wrist and the strap of the smartwatch, especially after sweating

during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product.

Do not wash the strap with a household cleanser. Please use soap less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.

For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.

 Do not disassemble, bore or damage the battery. Close all the programs on the watch → Stop and restart Bluetooth and GPS → Connect again

· Do not disassemble the built in batteries of non-replaceable battery devices.

Do not use sharp objects to remove the battery.

SAFETY & PRODUCT INFORMATION

Health Warning

 If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch.

 The optical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician before wearing this device.

· The device tracks your daily activities through sensors. This data is intended to tell you about your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely accurate. . The device accessories, heart rate sensor, oxygen level monitor, and other relevant data is

designed for fitness and not for medical purposes. They are not applicable to the diagnosis.

monitoring, treatment or prevention of any diseases or symptoms. The heart rate and blood pressure data are for reference only. We're not responsible for any deviation in data. · Avoid wearing the watch too tightly. Make sure you keep your skin dry - the area that comes in contact with the watch. If symptoms such as redness or swelling appear on your skin,

Call & Text Notifications, Find My Phone, music control, camera control, weather forecast, cloud immediately stop using the watch and consult the doctor.

Things to keep in mind Sync data everyday days to avoid data loss.

Water Resistance will not work for seawater, acidic and alkaline solutions, chemical

Sports modes support up to 6 hours of exercise at a time.

Disclaimer: This product is an electronic monitoring product and is not intended as a

described in this manual without any prior notice. At the same time, we hold the right to continuously update the product content.

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

toxic substances.













reagents & other corrosive liquid. The damage or defects caused by misuse or improper use are not covered by the warranty.

· Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch

· Keep your arm still while measuring data for accurate measurement.

medical reference. We reserve the right to modify or improve any of the functions

Old electrical appliances must not be disposed of together with the residual waste. but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort you contribute to recycle valuable raw materials and treatment of









