



eze™ Mattress Care Guide

eze™ Hybrid Ultra

eze™ Hybrid Ultra Mattress Features

Mattress Depth

- 28cm.

Sleep Surface

- Hypoallergenic breathable soft knit stretch fabric sleep surface for ultimate comfort.

ezeCORE Foam Layer

- High density foam layer providing a stable core preventing sagging over the life of the mattress. Extensively tested for stability to deliver support and pressure-relief for all body types.

MEMOREze foam layer

- Provides support and pressure relief by contouring to your body and helps to dispel body heat.

Pocket Springs

- Independently encased 800 pocket spring unit which conforms and adjusts to individual body contours to help to eliminate roll together for undisturbed sleep.

Anti-Slip Base

- Helps keeps your mattress in one place. Durable and fire retardant.

How to care for your eze™ hybrid mattress

Toppers & Cleaning

- Allow the mattress to be aired whilst it expands to freshen and remove any aroma from storage and packaging.
- Use a washable mattress protector to prolong the life of the mattress and to prevent stains on the soft knit stretch fabric cover.
- Spills should be absorbed with a dry cloth and sponged with a slightly damp cloth and a mild detergent, should any accidents happen.
- Clean the mattress sleep surface with a soft brush or Hoover every couple of months.

Settlement

- Body shaped impressions, sometimes called settlement, are normal characteristics of a quality mattress. This is caused by the mattress adjusting to your body shape. It can take up to 6 weeks for your mattress to fully adjust. Rotating the mattress as described below will benefit this process.

Rotating the mattress

- It is very important your eze™ mattress is rotated 180 degrees on its base regularly, thereby minimising the settlement of the cushioning layers. eze™ mattresses only have one sleeping surface so cannot be flipped over. We recommend rotating your mattress every month.

Bed Bases

- eze™ mattresses are suitable for all bedframes, however, we recommend checking the weight capacity of your bedframe with the manufacturer, for example, the eze™ Hybrid Ultra King or Super King may be too heavy to lift up to access storage for an ottoman bed.

Handling

- Many of our mattresses are heavy and you will need help when rotating or moving your mattress. The handles provided are ideal for rotating but are not designed to carry the mattress far.
- Do not roll or fold the mattress once it has been unrolled onto the bed as this can damage the internal components.
- Sitting on the edge of the bed puts undue strain on the springs at the edges and can damage the mattress border.



<https://ezemattress.com/>
Email: info@ezemattress.com
Phone us: 03303112133