The Key Combinations Table of Keychron K8

For the Keychron K8, we've included all the normal and useful function keys that can be accessed via the key combinations. Here is the table for all the key combinations and functions it can access.

fn + Keys	
Кеуѕ	Function
fn + -	RGB Speed Decrease
fn + =	RGB Speed Increase
fn + 1	Select Bluetooth device #1
fn + 2	Select Bluetooth device #2
fn + 3	Select Bluetooth device #3
fn + 1	Pair with Bluetooth device #1
(long press for 3s)	
fn + 2	Deinwith Dhugtagth device #2
(long press for 3s)	Pair with Bluetooth device #2
fn + 3	Pair with Bluetooth device #3
(long press for 3s)	
fn + Light Effect Key	Turn On / Off the Backlight
fn + Right Arrow	Change The Backlight Color
(Only Works for RGB-backlit Version)	
fn + Left Arrow	Change The Packlight Color
(Only Works for RGB-backlit Version)	Change The Backlight Color
fn + F1	F1
(Mac mode)	
fn + F2	F2
(Mac mode)	FZ
fn + F3	F3
(Mac mode)	F5
fn + F4	F4
(Mac mode)	
fn + F5	F5
(Mac mode)	
fn + F6	F6
(Mac mode)	
fn + F7	E7
(Mac mode)	F7
fn + F8	F8
(Mac mode)	

fn + F9		
(Mac mode)	F9	
fn + F10	F10	
(Mac mode)		
fn + F11	F 4.4	
(Mac mode)	F11	
fn + F12	F12	
(Mac mode)	F12	
fn + F1	Scroon Brightness Down	
(Windows mode)	Screen Brightness Down	
fn + F2	Scroop Prightnoss Up	
(Windows mode)	Screen Brightness Up	
fn + F3	Launches Mission Control	
(Windows mode)		
fn + F4	Launchpad	
(Windows mode)		
fn + F5	Keyboard Backlight Down	
(Windows mode)		
fn + F6	Keyboard Backlight Up	
(Windows mode)		
fn + F7	Rewind	
(Windows mode)	Newind	
fn + F8	Play / Pause	
(Windows mode)		
fn+ F9	Fast Forward	
(Windows mode)		
fn + F10	Sound: Volume Mute	
(Windows mode)		
fn + F11	Sound: Volume Down	
(Windows mode)		
fn + F12	Sound: Volume Up	
(Windows mode)		
fn + Win	Lock / Unlock the Win Key	
(Windows mode, long press for 3s)	(Only Works for Non-backlit Version)	
* Press Light Effect Key to change light effect		
More key combinations		
Кеуѕ	Function	

	Check Battery
	(Still in Beta, not 100% accurate)
fn + B	
	RGB-Backlight Version
	Backlight Red = 0~30% Power
	Backlight Blue = 30%~70% Power
	Backlight Green = 70%~100% Power
	White-Backlight Version
	Two Rows Backlight off & the Other On =
	0~30% Power
	One Row Backlight off & the Other On=
	30%~70% Power
	All Backlight On = 70%~100% Power
	Non-Backlight Version
	#1 Backlight Red= 0~30% Power
	#1 #2 Backlight Red = 30%~70% Power
	#1 #2 #3 Backlight Red = 70%~100% Power
fn + S + O	Disable / Enable the Auto Sleen Mede
(Bluetooth mode, long press for 3s)	Disable / Enable the Auto Sleep Mode
fn + S + L + R	Auto Sleep in 10 Minutes Without Typing
(Bluetooth mode, long press for 3s)	Auto sleep in 10 windles without Typing
fn + S + L + T	Auto Sleep in 20 Minutes Without Typing
(Bluetooth mode, long press for 3s)	
fn + S + L + Y	Auto Sleep in 30 Minutes Without Typing
(Bluetooth mode, long press for 3s)	
fn + J + Z	Reset the Keyboard
(long press for 3s)	
fn + X + L	Switch Between Function Keys and
(Windows mode, long press for 3s)	Multimedia keys (F1-F12)
fn + K + C	Switch Between Function and Multimedia
(Mac mode, long press for 3s)	Keys (Only works for F5 and F6)
fn + L + Light Effect Key	Lock / Unlock the backlight effect
(long press for 3s)	