



# HyperBrite™ Strobe

## USAGE INSTRUCTIONS

- >> Press and hold power button for 2-3 seconds to turn on.
- >> Press repeatedly to cycle through modes.
- >> Press and hold power button for 2-3 seconds to turn off.

## TO REPLACE BATTERY:

- 1 Locate notch on bottom of HyperBrite under power button.
- 2 Using a coin or flat head screw driver insert into notch and gently turn to remove back of HyperBrite.
- 3 Replace two CR2032 batteries, positive (+) side face up.
- 4 Put backing in place and squeeze until front and back snap together.

