



HyperBrite Orb™

USAGE INSTRUCTIONS

- >> Press and hold power button for 2-3 seconds to turn on.
- >> Press repeatedly to cycle through modes.
- >> Press and hold power button for 2-3 seconds to turn off.

TO REPLACE BATTERY:

- >> Locate notch on bottom of HyperBrite Orb under power button.
- >> Using a coin or flat head screw driver insert into notch and gently turn to remove back of HyperBrite Orb.
- >> Replace two CR2032 batteries.
- >> Put backing in place and squeeze until front and back snap together.

