


SMART PROJECTOR

User Manual



Prima Projector

First of all thank you for using our smart projector!

Please read this manual carefully before using so it will help you to quickly be familiar with this product.



CONTENTS

Interface/Button Diagram	1
Remote Control	3
Language Setting	3
Power on/Power off	4
Sharpness	4
Home	5
App Center	5
Settings	6
WI-FI Setting	6
Hotspot Setting	7
Bluetooth Setting	8
Screen Share	9
File Browser	10
APP Install/Uninstall	11
Factory data reset	12
Notes	12

1. Interface/Button Design


Projector Model: X2

Size: 78.5mm * 46mm * 8mm




2. Remote Control

Projector model	Remote control
X2	IR wireless



3. Language Settings

Enter "Settings > "Language Settings" and select the language you want to switch.



4. Power ON/OFF

Projector Model: X2

Power ON : Switch down the [ON/OFF] on the left side of the projector and wait for the screen to display.


Turn on the device with the switch on the side and hold down the power button in touch screen for 5-10 seconds, The projection light will on immediately.

Power OFF : Switch down the [ON/OFF] on the right side of the projector, the interface of shutdown will pop up, click "OK" to shut down, after the projector stops running, please switch the[ON/OFF] up to the top, otherwise the battery will still be in a power-consuming state.


5. Sharpness

Turn the focus gear on the left side of the projector to adjust the picture sharpness.


6. Home



7. App Center





8. Settings



9. Wi-Fi Settings


Enter "Settings" > "Networking Selling" > "WI-FI Setting", click the switch to "ON" state, select the network which you want to connect, enter the password and click "Link".





10. Hotspot Setting


Enter "Settings" > "Networking Setting" > "Hotspot Setting", click the switch to "ON" state, you can set the parameters, click "OK", and then the projector's hotspot can be searched by other devices to share the network.





11. Bluetooth Settings

Enter "Settings"> "Bluetooth Setting", click the switch to the "ON" state, search for the device which you want to connect, pairing.



12. Share Screen

Method one: need to download the APP (recommended for iPhone/iPad/Windows/Android)

The phone and the projector are connected to the same network, or in the absence of a network, the phone is connected to the hotspot of the projector.

(Details of the hotspot setting method, see 10.)

Enter the APP "EShareServer" on the projector and follow the steps of the screen.



Method two: no need to download the APP

Miracast(for Android system):

- The phone and the projector are connected to the same network.
- Enter the APP "Miracast" on the projector.
- Enter "Settings" > "More" > "Wireless Display" on the phone, and click the name of the device to match.

airplay(for iOS system):

a. The phone and the projector are connected to the same network, or in the absence of a network, the phone is connected to the hotspot of the projector.

(Details of the hotspot setting method, see 10.)


b. Enter the APP "airplay" on the projector .


c. Open the "Screen Mirroring" on the iPhone/iPad, and click the name of the device to match.

13. File Browser

Read: Insert the U disk/TF card, enter the "File Browser".

Edit: Select the menu icon  , tick the file you want to operate . deselect the menu icon  , select the options you want to operate in the edit  icon directory .

If "Cut" or "Copy" is selected, you need to first select the directory, and then click the edit icon  to select "Paste".




14. App Install/Uninstall

APP Install : If the APK Downloaded, enter the "App Center" > "App Installer", find the location of the APK, click and install it; If the APK is not downloaded, you can download and install it in the "Google Play".




APP Uninstall : Enter "Settings" > "Other Setting" > "Apps", click the App that needs to be uninstalled.



15. Factory Data Reset

Enter "Settings" > "Other Setting" > "Backup & reset" > "Factory data reset" > "RESET MBX".



16. Notes

- Make sure to use a standard power adapter. Other adapters may cause serious damage to the projector.
- Please keep the lens clean, dirt or scratches will affect the projection effect.
- Before you clean the projector, disconnect the power supply, clean it with a clean cotton wool or soh cloth, and then wipe off the residual moisture with a dry cloth.
- Do not place or drop hard objects on the projector.
- Do not place the projector on your legs or any part of your body to prevent injury from the heat.
- Avoid using the projector during weather of high humidity or thunderstorms.



Prima Projector

