



GAUGE HARNESS KIT

This kit prevents your behind-the-dash wiring from turning into a rat's nest.

Use the diagram below to correctly connect all your gauges' wires.

If your gauges have studs & nuts instead of blade connectors, connect the harness wires with ring terminals or convert to push-on type terminals.

If your dash lights have a single wire, connect to the brown wire and attach the black wire to the gauge mounting bracket using a ring terminal.

If your indicator lights have push-on terminals, remove the butt connectors from the harness and replace with push-on terminals.

Installation of Wires on Gauges:

Speedometer:	Bonded wires to Sensor Red/White to Battery + Black to Ground
Tachometer:	Purple to Sender Red/White to Battery + Black to Ground
Fuel Gauge:	Pink/Black to Sender Red/White to Battery + Black to Ground
Oil Pressure:	Blue/Black to Sender Red/White to Battery + Black to Ground
Water Temp:	Light Green to Sender Red/White to Battery + Black to Ground
Voltmeter:	Red/White to Battery + Black to Ground
Dash Lights:	Brown/Black to Dash Lights + Black to Ground
Left Indicator:	Blue/White to Indicator + Black to Ground
Right Indicator:	Blue to Indicator + Black to Ground
High Beam Indicator:	Green to Indicator + Black to Ground

